


## Finger PTT Button



## How to use Finger PTT Button



How to power on/off PTT button?

Press and hold the power button on the side to turn on or off the PTT button. When power on, blue indicator will be on. Indicator will be off when power off or running low of battery.

## How to pair PTT button with Smart Ski Goggles

**Step 1** Press and hold the Up button on the Smart Ski Goggles to enter the pairing mode



**Step 2** Make sure the PTT button is power off



**Step 3** Press and hold the PTT button first. Then press and hold the power button on the side at the same time until indicator LED turns on



**Step 5** Release the power button after indicator light is on for 3 seconds. Then indicator light flashes.



**Step 6** When indicator light stop flashing, release PTT button. When pairing is successful, intercom icon will show on display of Smart Ski Goggles.

## FCC warning words

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Smart wireless intercom audio ski goggles

## Smart wireless intercom remote control User Manual

G01K