



USER MANUAL



8"
Android™ 13
Tablet

Cautions

This user manual has been specially designed to guide you through the functions and features of your device.

- 1) Please read this manual carefully before using your device to ensure safe and correct use.
- 2) The descriptions in this manual are based on the default settings of your device.
- 3) Do not use this unit near water. Do not place over the unit any container with liquid inside.
- 4) Please do not put your device in high temperature, moisture or dust place. The tablet is not waterproof.
- 5) Avoid falling or violent collision. Do not violently shake the touch screen, otherwise, it could lead to damage or display abnormal.
- 6) If system shutdown automatically, it means the battery may used up, battery charging is required.
- 7) Please charge the tablet regularly if not in use for a long time to avoid the damage caused by the excessive consumption of battery.
- 8) Do not disassemble or use alcohol, thinner or benzene class to swab product surface.
- 9) Please do not use the tablet when driving or walking in the street, otherwise it may lead an accident.
- 10) Please choose the appropriate volume, if had tinnitus, please lower the volume or stop using.
- 11) Memory space available is nominal, as the android system itself takes up part of the memory space and the operation of the program will also take up space.
- 12) Storage capacity available is nominal, as the android system occupies about hundreds of MB storage capacity. And in order to install the software needs, the system must reserve certain storage capacity, so the actual usable space is less than nominal space.
- 13) When CPU operates in high speed, especially playing 3D games or High-definition video for a long time, the fuselage will have fever.
- 14) Please keep this manual for future reference.
- 15) The battery is contained with the device, please do not take out the battery.

Catalog

Chapter One: Overview

- 1.1 Appearance.
- 1.2 Buttons.
- 1.3 Power on and off.
- 1.4 Open and close standby mode.
- 1.5 Lock and unlock the screen.
- 1.6 Homepage information bar.
- 1.7 Text input.
- 1.8 Reset.
- 1.9 USB connection.
- 1.10 Accessories.

Chapter Two: Internet

- 2.1 Browser.

Chapter Three: Application

- 3.1 File manager.

Chapter Four: System setting


- 4.1 Wireless networks setting.
- 4.2 Sound setting.
- 4.3 Display setting.
- 4.4 Apps setting.
- 4.5 Security setting.
- 4.6 Language and input setting.
- 4.7 Date & time setting

Chapter Five: Specification

**GUIDE TO USING TABSERA LEARNING APP
FOR PARENTS AND STUDENTS**

Chapter One Over view

1.1 Appearance



1. Touch LED Panel
2. Front Camera
3. Rear Camera
4. Power key
5. Volume +/- key
6. Speaker
7. TYPE-C Port
8. Micro TF
9. Headset input 3.5mm

1.2 Buttons

Power button

Long press the power button 2-3 seconds to turn the unit on. When the tablet is in operation, short press power button to enter the off-screen state and short press it again to light up the screen.

Volume

Press Volume+/- to adjust the volume.

1.3 Power on and off

Power on

Long press the power button 2-3 seconds, pictures will show up until to the interface.

Power off

Long press the power button, choose Power Off to shut down.

1.4 Open and close standby mode

Open the standby mode

When the tablet is in operation, you can press the power button to go to the standby mode which can save power.

Close the standby mode

When the tablet is in standby mode, you can press the power button to light up the screen and the unit will back to normal state.

1.5 Lock and unlock the screen

Lock


You can set the sleep time in the system of display.

The system will sleep automatically and lock the screen to the standby mode if without any activity when reaches the preset standby time.

Unlock


Drag  to unlock the screen and enter the application interface.

1.6 Homepage Information Bar



1.7 Text Input

When use the tablet, you can use the virtual keyboard to input text, number, symbols directly by touching screen. After selecting the Android input method, the default keyboard show as below:



To switch the numbers and letters, press 

To switch the capital and lowercase letter, press 


1.8 Reset

Use a thin object (like the end of a paper clip) to press the reset button in the hole, then your device will shut down, you need to press the power button to turn on the unit.

1.9 USB connection

Use the USB cable to connect the tablet with PC, Click the drop down bar and you will see Changing this device via USB
Tap for more options., click this sign to connect your device.

Turn off USB storage to disconnect your device with PC.



1.10 Accessories

Power Adapter	1
USB Cable	1
User manual	1
Protective cover	1
Passive pen	1
Earphone	1
OTG Cable	1

Chapter two: Internet

2.1 Browser

Require network support before using a web browser, if there are network supporting problems, please contact your network operator or the service provider.

Tablet's web browser can connect to the Internet via WiFi to satisfy your business and individual network needs .

Please touch  (Settings) to set up the WiFi so that you can use the browser normally.

Touch  (Chrome) in the application list to enter the browser pages.



Input URL: Touch the input area to get the soft key board, then input the URL.

Touch  to show the submenu of the browser, and choose the corresponding one accordingly.

Chapter Three: Application

3.1 File Manager

Touch  (File manager), you can copy files among SD card, USB and internal memory.

Chapter Five(Specification)

Dimension(mm*mm*mm)	124.4x208.8x9.9mm
Weight	Appro x 340g
LCD	800*1280IPS
OS	Android 13
Processor	MT8183
Memory	4GB RAM,32GB Storage
WI-FI	802.11b/g/n/ac
Connections	TYPE-C,TF Card,Headphone jack
Battery	3.7V/3500mAh
Servicetime	Up to 4h video
Operatingtemperature	Between0°C et40°C



If at any time in the future you should need to dispose of this product please note that waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. (Waste Electrical and Electronic equipment Directive)

- Owing to continuous improvement, no prior notice will be given regarding changes on above feature and spec.

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Specific Absorption Rate (SAR) information

This TABLET PC meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: TABLET PC has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the TABLET PC kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the TABLET PC. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.