


MEDIA COUS

LED FLOOR LAMP

Model: ME-FL01

User Manual



Specifications

Adapter Input	AC 100-240V 50/60Hz
Adapter Output	DC 24V === 0.5A
Lamp Power	12W Max
Color Temperature	2700K-5700K
Luminous Flux	650lm
Lifespan	50,000H

IMPORTANT SAFETY INSTRUCTIONS



READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE


- ◆ To ensure correct installation and function, always follow the instructions in the User Manual.
- ◆ Use only the provided power adapter.
- ◆ DO NOT dismantle or modify by yourself. Always ask authorized person for repair.
- ◆ DO NOT place or operate near extreme heat sources, moisture, or corrosive substances.
- ◆ DO NOT operate with a damaged cord or after malfunction occurs, or damaged in any manner.
- ◆ DO NOT remove the power plug with wet hands as it may cause electrical shock.
- ◆ Always unplug prior to installation, maintenance or carrying out any repair activities.
- ◆ DO NOT clean with detergents or other solvents. Wipe with a soft dry cloth.
- ◆ Follow local regulations regarding disposal or recycling of the lamp and components.

SAVE THESE INSTRUCTIONS

ASSEMBLING FLOOR LAMP



- Strictly follow the steps as instructed to assemble the lamp properly. Make sure that the lamp is assembled properly and securely before use.
- Hold the lamp pole when adjusting the goose neck. Do not rotate the goose neck excessively.



- 1 Screw the section 1 into the lamp base.
- 2 Screw the section 2 into the section 1.
- 3 Screw the section 3 into the section 2.
- 4 Plug in the cable, then screw the section 4 into section 3.
- 5 Connect with the power adapter, then plug into an outlet.

USING FLOOR LAMP



- DO NOT touch the lamp head with your bare hands when in use.
- This lamp is designed with power off memory function. It will always remember your last settings (except timer) once you turn it on again.

Using with Control Panel



Auto OFF Timer

With lamp on, tap once to turn on 60min auto OFF timer (button indicator flashing). Tap once again to cancel timer (button indicator off).



Color Temperature Adjustment

• With lamp on, tap repeatedly to cycle through 5 color temperatures.
• With lamp on, hold to steplessly adjust the color temperature.



Brightness Adjustment

• With lamp on, tap repeatedly to cycle through 5 brightness levels.
• With lamp on, hold to steplessly adjust the brightness level.



Power ON/OFF

Tap to turn on or turn off the lamp.



Night Light

• Hold for 2s to turn on night light.
• To exit night light mode, tap ☀ on control panel or any button (except ☀ / ⏻ / ⏻) on remote control.




Power Button Indicator

With lamp off, hold ☀ and ⏻ simultaneously for 2s to turn off or turn on the power button indicator.

Using with Remote Control



The remote control is paired with your lamp by default. If not paired, unplug and re-plug in the lamp, then manually pair by holding and simultaneously within 30s after powered on until the lamp flashes. Effective range: 49.2ft. / 15m.



TROUBLESHOOTING GUIDE



The troubleshooting guide addresses the most common problems. If problems persist, feel free to contact the Customer Support via email: support@mediacoushome.com

Q: My lamp does not light up or turn off suddenly.

A: • Make sure the lamp is properly connected to the electrical outlet with the included power adapter.
• Check if you have enabled Auto OFF timer. Tap the power button to turn it on again.

Q: The light flickers.

A: • Make sure the power adapter and plug are inserted fully and securely.
• Connect the power adapter only to the electrical outlet without dimmer switch.


Q: Remote control does not respond to the lamp.

A: • Check if the battery in remote control is enough in power.
• Remove the obstacles between the lamp and the remote control.
• Try pairing the remote control manually. Unplug and re-plug in the lamp, then hold and simultaneously within 30s after powered on until the lamp flashes. Then your lamp is successfully paired with the remote control.

Installing & Replacing Battery



• Replace with new battery of the same type (AAA Alkaline) when necessary.
• When not using the remote control for extended period of time, take out the batteries.
• DO NOT attempt to dismantle the batteries.
• DO NOT dispose the batteries in fire, batteries may explode or leak.



CERTIFICATION



FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)
(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

IC Warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes:
(1) Ce dispositif ne peut causer d'interférences ; et
(2) Ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Questions or Concerns?

support@mediacoushome.com



Manufacturer: Shenzhen Guiyang Network Technology Co., Ltd
Address: 1404K3, East Block, Shengtang Commercial Building, Futian District, Shenzhen, China
Rev_1.6_EN Made in China