


1

2

3

<div></div> <div><b>MINI WIRELESS MOUSE</b> model 2604759</div> <div>USER MANUAL</div> <div>Thank you for purchasing RadioShack's mini wireless mouse!</div>	<div><b>PACKAGE DETAILS</b></div> <div><ul style="list-style-type: none"><li>• <b>1 2.4G wireless optical mouse</b></li><li>• <b>1 mini USB receiver</b></li></ul></div> <div><b>FEATURES</b></div> <div><ul style="list-style-type: none"><li>• Dimensions: L87 x W56 x H30mm</li><li>• 3-button</li><li>• 1,000DPI</li><li>• Snap-in Nano receiver</li><li>• 1 AAA battery (not included)</li><li>• Windows XP/Vista/WIN8/WIN10</li></ul></div> <div><b>TECHNICAL PARAMETERS</b></div> <div><ul style="list-style-type: none"><li>• The mouse's rated voltage is 1.5V and the rated current is 25-30mA.</li><li>• 2.4G wireless radio frequency technology.</li><li>• Working distance: up to 10M.</li><li>• Multi-level sleeping function, helps you save more power.</li><li>• Low power and low current consumption design, prolonging battery life longer.</li><li>• Plug and play, easy!</li><li>• Ergonomic and comfortable design, easy operation.</li></ul></div>	<div><b>INSTALLATION</b></div> <div><ul style="list-style-type: none"><li>• Open the battery cover at the bottom of mouse and insert the AAA battery in the correct direction. When the battery is installed, the LED light will light up for 2 seconds and then it will turn off. This means the mouse is in working state.</li><li>• Connect the receiver on your computers USB input.</li><li>• You can now use your mouse.</li></ul></div> <div><b>IMPORTANT</b></div> <div><ul style="list-style-type: none"><li>• When you unplug the receiver or host shuts down, the mouse will immediately stop working (sleep mode).</li><li>• When mouse is in sleep mode, you can wake it up by pressing any button.</li><li>• When you connect the receiver or reboot the computer, you should click any button, LED will light up; this means the mouse is in working state.</li></ul></div> <div>You can use this mouse on any surface except glass.</div>
---	---	---

正面

4

5

6

<div><b>TROUBLESHOOTING</b></div> <div><b>• IF DOESN'T WORK, WHAT CAN WE DO?</b></div> <div><ol style="list-style-type: none"><li>1) Check if the battery positive and negative electrode is right.</li><li>2) Check if the USB receiver is connected correctly.</li></ol></div> <div><b>• WHEN THE MOUSE MOVES SLOWLY OR MALFUNCTIONS, WHAT CAN WE DO?</b></div> <div><ol style="list-style-type: none"><li>1) Increasing the distance between mouse and other computer equipment.</li><li>2) Turn off other wireless devices, it may affect the transmission and extend the mouse's response time.</li></ol></div> <div><b>WARNING</b></div> <div>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div>	<div>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div> <div><b>NOTE:</b> This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</div> <div>If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div>	<div>—Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help</div> <div><b>NOTE:</b> This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.</div> <div>RF exposure: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</div>
---	---	--

背面