




2767C

3.15" (80mm)

WIRELESS MOUSE MANUAL

Functional Instructions



Main Specifications

1. PRODUCT: WIRELESS SINGLE-MODE MOUSE
2. CONNECTION MODE: BLUETOOTH
3. DPI: 800-1200-1600
4. BATTERY: ONE AA DRY CELL BATTERY
5. FCC ID: 2BDVY-Y11

Wireless Connection Method

1. OPEN THE BATTERY COVER AT THE BOTTOM OF THE MOUSE, INSERT THE BATTERY, AND CLOSE THE BATTERY COVER.
2. FIND THE POWER SWITCH ON THE BOTTOM OF THE MOUSE AND SWITCH IT TO THE ON POSITION. ONCE ON, THE RED LIGHT AT THE BOTTOM OF THE MOUSE WILL LIGHT UP.
3. TURN ON THE COMPUTER' S BLUETOOTH, SEARCH FOR BLUETOOTH DEVICES, AND FIND THE NAME BT5.2MOUSE. IT WILL AUTOMATICALLY PAIR TO COMPLETE THE CONNECTION.
4. AFTER COMPLETING THE PAIRING CONNECTION, THE RED LIGHT ON THE BOTTOM OF THE MOUSE WILL ALWAYS BE ON, AND YOU CAN USE THE MOUSE.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution:

Changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Responsible party

Designed in Austin, Texas. Made in China. All designs @ 2024 Packed Party, Inc. All Rights Reserved. Packed Party is a registered trademark of Packed Party, Inc.

Packed Party, Inc. 3205 Industrial Terrace, Suite 200, Austin, Texas 78758
www.packedparty.com

3.29" (84mm)

折痕线