

# Instructions for using the X-360 handle

## Connecting Windows devices


- Only X-360 controller with Bluetooth function is supported
- The Windows device system version is required to be Windows 7 SP1 or higher.
- Does not support functions such as trigger vibration and 3.5mm headphones

1. Connect the receiver to a Windows device USB port.
2. Gently press the pairing button of the receiver to enter the search handle state, and the status indicator light quickly flashes.
3. Gently press the X-360 key to turn on the handle, then press and hold the pairing key for about 3 seconds to make the handle visible, and the indicator light quickly flashes. (Pairing is only required for the first connection, and the connected handle can be automatically connected the next time it turned on)



4. Wait for the receiver and handle to automatically pair and connect. After completing the connection, the handle will briefly vibrate and the status indicator lights of the receiver and handle will always be on.

## Key position correspondence (X-360 handle)



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction