Contents Earphone (Pair)X 1 Charging Cable X 1

Earphone Buds (Pair) X 5

wearer's ears for



Press here to hear a notification

■ Status Indicator

LED is constantly on when charging

when fully charged

Low Battery Notify four times

LED is off

Power ON/OFF & Bluetooth Pairing

Power ON/OFF

Take both earphones out and search for the Bluetooth

A notification will be heard when the Bluetooth is paired

Earphones will power off automatically if the Bluetooth

is disconnected for 3 minutes. Please put both

earphones back into the charging case to restart.

device. Start to pair "RÖtt KRÖN Bang"

and then press twice

Activate: Remove the insulation films and put both earphones back into the charging case

Charge: Earphones will power off automatically and start charging when put back into the charging case

Manual Power Off: Hold both touch controls for 3 seconds Manual Power On: Hold both touch controls for 3 seconds

Hold the right touch control for 1.5 seconds to play the next song

№ Play Music

Hold the left touch control for 1.5 seconds to play the previous song

№ Switch Modes

Double press either side to

Press the left touch control

control once to volume up

pause or play music

once to volume down

Press the right touch

ANC is off by default at powering on A notification will be heard when the Bluetooth is

> Press either touch control thrice to switch between three modes:

extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

1.ANC ON 2.Transparency Mode 3.ANC OFF

& Handle Calls

% Launch Cellphone

Press either touch control

four times to launch the

cellphone assistant

Assistant

Double press the left/right side to answer/end a call

Hold either touch control Factory Reset for 2 seconds to reject a cal

ENC is automatically turned on during a call

control simultaneously thrice; when LED flashes, the earphones are reset successfully

 Max Rated Input Voltage for Charger: 5.5V . Charge at prescribed voltage.

- The actual battery life varies with service conditions.
- * Exposure to humidity, heat or chill for long may cause fire, inflation, deformation and explosion.
- Voice Assistant is only available when your cellphone supports this function; it is unavailable during a call.
- When either earphone is disconnected, please put both ones back into the charging case to restart; Please perform a factory reset if reconnection fails.

Warning

Monaural Mode

If you only use one earphone, please turn off the other manually or put it back into the charging case

- 1. Take out both earphones and hold the two touch control simultaneously for 3 seconds till LED flashes
- 2. Wait for 3 seconds and then hold the touch control simultaneously for 6 seconds till LED is
- 3. When LED is constantly on, press the touch

-- Increase the separation between the equipment and receiver.

no guarantee that interference will not occur in a particular installation.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept

This equipment has been tested and found to comply with the limits for a Class B digital device.

protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio communications. However, there is

If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the

any interference received, including interference that may cause undesired operation.

pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

changes or modifications not expressly approved by the party responsible for compliance

Consult the dealer or an experienced radio/TV technician for help.

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

FCC Regulatory Compliance

could void the user's authority to operate the equipment.

FCC SAR statement

FCC ID:2BDZ6T302

environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the head

RÖtt KRÖN - Bang



























Qualcomm Active Noise

Qualcomm QCC3040, Qualcomm TrueWireless Mirroring, Qualcomm Active Noise Cancellation, Qualcomm aptX, and Qualcomm cVc are

Qualcomm and Qualcomm TrueWireless are trademarks of Qualcomm Incorporated, registered in the United States and other countries. aptX and cVc are trademarks of Qualcomm Technologies International, Ltd., registered in the United States and other countries.

Polycrystalline Zirconium Powder from Tosoh Japan 10mm Customized graphene HIFI dynamic Driver Play duration of earphone with charging case is about 24 hours









