

LED Wireless Charging Bluetooth Speaker User Manual

G63



Wireless charging usage:

Plug in the power adapter and connect the Type-c plug charging cable, and wireless charging function will automatically turn on.

Technical Parameters

Battery type: lithium battery 3.7V/300mA

Main functions: BT . TF . USB . AUX . Wireless charging, colored lights

Product size: 150*53*160mm

Speaker specification: 36mm 4Ω 3W

Wireless charging power: 5W/10W/15W

Power input: DC5V/2A; 9V/2A

Button function operation instructions

1. Press and hold the power button for two seconds to turn on the speaker; in music mode, short press to play/pause, and double-click to make a call.
2. Short press to the next song, long press to increase the volume.
3. Short press to the previous song, long press to decrease the volume.
4. Short press the M button to switch the lighting mode; long press to enter the alarm clock settings.

Bluetooth function usage:

1. This speaker supports the use of Bluetooth devices with A2DP function. Firstly turn on the speaker, long press the M button to enter the Bluetooth mode. The blue light of the Bluetooth indicator light flashes with a voice prompt. At this time, the speaker. It is in the waiting for pairing connection state. Only in this state can it be paired and connected to the Bluetooth speaker.
2. Mobile phone connection:

Step 1: Turn on the Bluetooth setting switch of the phone in the phone settings, and click Search Device. Step 2: When the available device displays the G63 character, it means that the phone has found the Bluetooth speaker. Click G63 to enter the pairing mode. After the phone and the speaker are successfully paired, there will be a voice prompt. and shows connected.

Alarm settings:

Long press the M button to setting the alarm, single click the play button to select hours and minutes. When the hours or minutes are flashing, short press or long press the next and previous song buttons to adjust the alarm time. After adjusting the minutes, press the M button again, it will display OFF, then press the next and previous song buttons to setting the alarm on or off, and then press and hold M button to save the alarm settings.

Lighting usage:

- 1.G63 Bluetooth speaker is equipped with a variety of lighting effects.
2. The device starts with the warm light effect by default. Long press the M button and then tap the light button to adjust the light.

TF card/U disk function usage:

Insert the TF card/U disk into the card slot, and a corresponding voice prompt will appear. The product will automatically read the audio files in the card and play the loud and small sounds. Play, the user can use the speaker "+/-" buttons to control the sound.

Safety Instructions:

1. Do not expose the product to water or wet areas, such as bathrooms.
2. Please do not hit or drop the product hard to avoid any damages.
3. Please turn off the power when not in use for a long time.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.