


QUICK START GUIDE

5G/LTE CBRS
USB-C Dongle


1. Lift the SIM door and insert the Nano-SIM into the slot with the gold contacts facing downward. Push the SIM card gently with your finger card into the slot, not use any tools.



2. Plug dongle's USB type C cable into device (e.g. Notebook, etc). Do not connect it through another adapter or cable.




3. Check the Dongle's LED light, it should boot in about 30-40 seconds



4. Check that the Ethernet network is connected.
Note: DG505G dongle supports Windows 11, Windows 10, Linux, Chrome OS, MacOS, iPadOS



5. For further network configuration, please log in to the Web UI. Enter `http://192.168.1.1` into your internet browser. You are now on your 5G dongle home page where you can check Cellular profile, signal strength, SMS and system time. Radio Equipment Regulation standards are also available at WebUI:
`http://192.168.1.1>Device>-Regulatory`



Regulatory information:

Model Name: DG505G

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device (FCC ID: 2BE94DG505G)) has also been tested against this SAR limit.

The highest SAR value reported under this standard during product certification for use when properly worn on the body is 1.194 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 5mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 5mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be Avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 5mm must be maintained between the user's body and the device, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.

Enjoy Your DG505G

