



Active Stylus Pen  
USER'S MANUAL




How to Work


Press the button to turn on (indicator light on)  
Press and hold the key to turn off (indicator off)  
Press the switch button to switch the tool



Turn on the iPad and turn on the Bluetooth connection  
Instant view of battery power




How to replace the spare Tip  
Take off the plastic Tips as the photo




Charging mode

Magnetic suction charging/storage



Magnetic charging device  
for iPad Pro 11-inch (1st&2rd&3rd&4th)  
for iPad Pro 12.9-inch (3rd&4th&5th&6th)  
for iPad Air 4  
for iPad Air 5  
for iPad mini 6

The USB cable is connected with the USB charger, Magnetic suction charger and pencil Wireless charging



Specification

Model:C10

Size:165x8.9mm

Battery:Li-polymer 100mAh

Charging mode:iPad adsorption  
wireless charging  
/Wireless charging Cable

Charging Time:60 Minute

Working Time:12 Hours

Tip Size:1.7mm

Sleeping Protect:: 10 minute static  
automatic sleep

Protection mode: Automatically shuts  
down in 15 seconds on full power

Compatible Device

iPad Pro 11-inch (1st&2rd&3rd&4rd)  
iPad Pro 12.9-inch (3rd&4th&5th&6th)  
iPad Air (3rd&4th&5th)  
iPad (6th&7th&8th&9th&10th)  
iPad mini (5th&6th)

Tips:

Only compatible with 2018/2019/  
2020/2021/2022 Apple iPad /  
iPad Pro/iPad Air/iPad mini Not  
support iPhone ,Android,Microsoft  
devices,earlier versions of iPad.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.