

尺寸:45×70mm (成品) 270×70mm (展开)—风琴折




联系我们

北京朗科创新科技发展有限公司
地址:北京市丰台区诺德中心二期11号楼
地址:深圳市南山区高新南区高新南六道10号朗科大厦
服务电话:400-105-5505
官方网址:www.netac.com.cn

Beijing Netac Innovation Technology Development Co.,Ltd.
Location: Building 11, Phase II, Nord Center, Fengtai District, Beijing
Location: Netac building, Number 6 High-tech South St.Nanshan District, Shenzhen, P.R.China 518057
Tel: 400-105-5505 (CN)
Web: www.netac.com

Product profile



1: Touch zone
2: Indicator light of earbuds zone
3: Charge contact/Mic
4: Indicator light of charge case zone
5: USB-C port

Power on/off

Power on: open the charge case cap, take earbuds out, earbuds turn on automatically.

Power off: put earbuds back to the charge case, close the charge case, earbuds turn off automatically.

* No device is connected to the host within 3 minutes, and the earbuds will automatically turn off.

Manual power on/off: Touch and hold on touching zone for 5 seconds.

Pairing and connection

1 Open the charge case cap, take earbuds out, left/right will turn on automatically. The main headset flashes red/white alternately.



2 The earbuds in the pairing mode, select Netac TW06 for pairing in the mobile BT menu.

* Paird status with mobile, if turn the BT off manually, earbuds will going to pairing mode automatically.

3 After successful connection, there is a reminder.

Music

► **Play/Pause:** tap touch zone once, music play or pause.

◄ **Previous song:** tap touch zone two times on left earbud.

► **Next song:** tap touch zone two times on right earbud.

Call

☎ **Calling accept:** tap touch zone once.

⤴ **Hang up:** tap touch zone once.

✖ **Calling rejection:** tap touch zone twice.

Vol

🔊 tap touch zone three times on left earbud.

🔊 tap touch zone three times on right earbud.

Active the voice assistance

Press and hold the touch zone for 2s to wake up/exit the voice assistant.

Factory reset

Keep earbuds in the state of unconnected, then fast tap the touching area for four times, there is a reminder. The headset flashes red/white alternately at the same time.

Charge


1 Earbuds will be charged automatically when put into the charging case. when fully charged, the indicator off.

2 The indicator of charging case will be steady on when fully charged.

Earbuds charging	Red light of earbuds is steady on
Earbuds fully charged	Red light of earbuds is off
Charge case charging	Light of charging case flashing
Charge case fully charged	Light of charging case is steady on

Specification


- **Product:** TW06
- **Headphone weight:** 4.8g*2pcs
- **Headphone size:** 36.9*21.5*21.5mm
- **Earbuds battery:** 3.7V 35mAh*2 (Lithium polymer battery)
- **Charge case recharge time:** 1.5hrs approximate
- **Music time:** 8 hrs approximate
- **Play time:** 30hrs (with charging case)
- **Charging case weight:** 37.9g
- **Charging case size:** 63.7*50.9*26 mm
- **Charge case battery:** 3.7V 300mAh (Lithium polymer battery)
- **Charge voltage and Ape:** DC 5V/ 300mAh
- **Range of transmission:** 10M



(封底)

(封面)

产品概述



1:多功能触控区 2:耳机指示灯
3:耳机充电触点/麦克风 4:充电仓指示灯
5:Type-C充电口

开机/关机

开机:取出耳机自动开机。

关机:耳机放入充电仓或3分钟内未与任何设备连接则自动关机。

手动开机/关机:长按多功能触控区5秒

蓝牙配对

1 打开充电仓,取出耳机自动开机。



2 开机后将左右耳机贴近,自动组队成功后指示灯灭。

3 打开设备蓝牙界面,搜索"Netac TW06",点击配对,连接成功并伴有提示音。

音乐

► **音乐暂停/播放:**播放时,单击多功能触控区。

◄ **上一曲:**双击左耳多功能触控区。

► **下一曲:**双击右耳多功能触控区。

通话

☎ **接听:**来电时,单击多功能触控区。

◄ **拒接:**来电时,双击多功能触控区。

✖ **挂断:**通话时,单击多功能触控区。

音量

🔊 + 三击左耳多功能触控区。

🔊 - 三击右耳多功能触控区。

唤醒语音助手功能(需手机支持)

长按2秒多功能触控区唤醒或退出语音助手(Siri)。

耳机恢复出厂设置

耳机在开机未连接设备的状态下快速双击多功能触控区,红白灯交替闪烁,同时耳机会有“哔”的一声提示音,会清除耳机里面的配对记录。

充电

1 耳机放入充电仓自动充电,充满后耳机指示灯熄灭。

2 通过充电线给充电仓充电,充满后充电仓指示灯点亮。

耳机充电	红灯长亮(耳机指示灯)
耳机充满电	红灯灭(耳机指示灯)
充电仓充电	灯闪烁(充电仓指示灯)
充电仓充满电	灯长亮(充电仓指示灯)

参数规格

- 型号: TW06
- 蓝牙版本: 5.4
- 耳机重量: 4.8g (单个)
- 耳机尺寸: 37.2*27.2*17.4mm
- 耳机电池容量: 3.7V 35mAh*2
- 耳机充电时间:约1.5小时
- 播放音乐时间:约8小时
- 充电仓重量: 37.9g
- 充电仓尺寸: 63.7*50.9*26 mm
- 充电仓电池容量: 3.7V 300mAh
- 充电仓给耳机充电次数: 4 次
- 支持协议:SPH/HFP/A2DP/AVCTP/HID
- 频率: 2.4GHz-2.48GHz
- 电源输入:DC 5V/300mA
- 蓝牙距离:10M

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 [Pb]	汞 [Hg]	铜 [Cu]	六价铬 [Cr(VI)]	多溴联苯 [PBBs]	多溴二苯醚 [PBDEs]
PCBA	×	○	○	○	○	○
塑胶部件	○	○	○	○	○	○
充电线	○	○	○	○	○	○
包装材料	○	○	○	○	○	○
电池	×	○	○	○	○	○

本表格依据 SJ/T 11364-2014 的规定编制
○ 表示该有害物质在该部件所有物质材料中的含量均在 GB/T 26572-2011 规定的限量要求以下。
× 表示该有害物质至少在该部件的某一物质材料中的含量超出 GB/T 26572-2011 规定的限量要求。

保修服务条例

感谢购买并使用朗科产品!为了使我们的服务让您更满意,购买后请认真阅读此质保卡并妥善保管。售后服务严格依据《中华人民共和国消费者权益法》、《中华人民共和国产品质量法》实行售后三包服务,服务内容如下:

1. 朗科真无线蓝牙耳机除依法实行三包外,自产品销售之日起,凭质保卡和发票或有效购买凭证,将享有七天无理由退货(电商购买渠道),十五天包换(品质问题),一年非人为有性能故障保修服务。

1)包换:真无线蓝牙耳机系列产品购买后十五天内,若发现非设备兼容性或非人为损坏的产品质量问题时,可和朗科或其授权服务站联系产品退换货服务(朗科只对产品主体进行更换,附件、资料、包装盒等不属于换货范围,更换产品只限于新品或功能正常的良品);

2)维修:真无线蓝牙耳机系列产品购买后一年内,若发现属于免费质保范围内的产品问题时,可和朗科官方联系维修服务,服务电话: 400-105-5505。

2. 产品若出现以下任一情况,将不属于免费质保范围:

- 1)超过质保期;
- 2)无法提供有效的产品质保卡和有效购买凭证或相应的复印件,擅自涂改质保卡;
- 3)未经朗科公司书面允许情况下的改造、拆装、维修而发生的故障;
- 4)产品上丝印或序列号激光码磨损、缺失;
- 5)产品充电接口由于外力造成弯曲、变形等异常现象,产品外观破损、变形等异常现象;
- 6)未按使用指南上(使用指南)的指示维护所导致的故障损坏;
- 7)产品的损坏是要不可抗力(如火灾、地震、洪水、台风等)人为损坏(如敲打、跌落、破裂、重击等)人为丢失(如落水、遗失、未妥善保管等)或其他非正常使用所致。
- 8)因物理或电子及电磁的压力或干扰,电源不稳定及误用、闪电、静电、火或其它不可抗力因素而造成的损坏;
- 9)因暴露或存放在不当的环境(包含高温、低温或高湿度的环境)而造成的损坏;

10)因送修至朗科公司维修站或授权服务站途中运送或包装不当而造成的损坏或遗失;

11)将朗科产品使用于研发、生产用途或专业测试所导致的故障或损坏。

3. 要求更换/维修产品时的规定:

- 1)请在需要换/维修产品时出示质保卡和发票或有效购买凭证;
- 2)质保卡丢失不补发,请妥善保管;
- 3)对更换的故障产品或维修更换的损坏零部件,公司有权处理,敬请谅解。

4. 其他声明:

- 1)若产品不符合免费质保范围或超出质保期,朗科将不予提供免费维修或退换货服务;
- 2)质保卡中记载的内容如有与国家规定不符之处,以国家规定为准;
- 3)相关事宜请点击朗科中文网站<http://www.netac.com.cn>查询。

质保卡

产品名称	
产品型号	
产品SN码	
购买日期	
用户姓名	
联系电话	
经销商名	
故障描述	

尺寸:45×70mm (成品) 270×70mm (展开) —风琴折

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2BEBP-TW06	
---	--