

KOSPET TANK T3 Ultra

User Manual

Download Multilingual User Manual (in PDF)

Please scan the QR code below for the user manual in multiple languages.




The supported languages include: English, French, German, Italian, Spanish, Turkish, Arabic, Russian, Ukrainian, Simplified Chinese, and Traditional Chinese.


Packing List

Smartwatch (including strap), Magnetic charging base, Tempered glass package set






Magnetic charging base x1



Tempered glass package set x1

Smartwatch (including strap) x1

About the Watch



Watch Charging

- Please fully charge the watch before use.
- The watch charger's USB port needs to be plugged into a power adapter or a computer's USB port.
- When placing the watch onto the magnetic charging base, it's required to keep the watch in a proper direction and position. Be sure that the metal contacts on the back of the watch are closely connected to the charging base.

Notes:

- Please use the KOSPET original magnetic charging base to charge the watch, before which be sure to keep the charging base dry and clean.
- Please use the power adapter with output current of 500mA or more, which is certified to meet safety standards.



Pairing and Connection

Download the KOSPET FIT App before using the smartwatch for more sports and health data, personal settings, and beyond, which helps you stride toward a healthier, more active lifestyle.

App Installation Methods:

Method one: Scan the QR code on the right to download and install the App.









KOSPET FIT

Method two: Enter "KOSPET FIT" on App Store or Google Play to download and install the App.






App Registration and Sign-in



1. Open the App, allow it to access Bluetooth, location, and grant other necessary permissions on your watch.



2. Register and sign in to the App.

Watch Pairing



1. Follow the prompts on the App to find and add the device (smartwatch).



2. Allow the watch to connect to the App on your smartwatch.

Note: Please don't pair the watch directly via your mobile phone's Bluetooth on Settings.

Watch Gestures





Shortcut Menu

Swipe down from the watch face to enter Shortcut Menu that can be customized by tapping Edit.





Notification Center

Swipe up from the watch face to enter Notification Center that can be customized by swiping to the bottom.





Unread Notifications

Swipe right on the watch face to view unread notifications.





App List

Swipe left on the watch face to enter the App list.



Watch You Want

Use of Physical Buttons

SEL button

- Short press on the watch face to enter the App list.
- Short press during a workout to pause, resume or end the workout.
- Short press on a confirmation page (e.g. with Confirm and Cancel) to confirm.
- Short press on Stopwatch or Timer to pause or resume the stopwatch or timer.
- Short press on the control center to enter Settings.
- Long press for 3s to power off, restart, or activate Emergency SOS.
- Long press for 12s to force a restart.





BACK button

- Short press on the watch face to open the workout list. Short press again to return to the watch face, which can be customized.
- Short press on other pages to return to the previous page.
- Short press on a confirmation page (e.g. with Confirm and Cancel) to cancel.
- Short press on Stopwatch to end the stopwatch, and return to the stopwatch list.
- Short press on Timer to reset the timer.
- Long press for 3s during a workout to end the workout and save workout details.
- Long press for 3s on the watch face to activate Voice Assistant.