

Manual



Charging bin power display
Fingerprint touch
Headphone indicator

Reminder: Before connecting the headset with your cell phone, please turn off the bluetooth, wait for the headset to complete the pairing, and then turn on the bluetooth.

Note: When using the headset, if you can only connect one headset, you need to delete the "S30" on the Bluetooth device, and then search for pairing again.

Operation Methods

1. Take out the headset, the left and right ear breathing light slowly flashing, that is, pairing success, fast jumping, the headset is not paired successfully; left and right headset pairing success, open the bluetooth device, click to connect the "S30" can be.

Function:

1. Press and hold for 1 second: open the voice assistant.
2. Touch 1 time: Pause/Play
3. Touch 2: Previous/Next song
4. Touch 3 times: Increase/decrease volume
5. Touch 3 down: Power on/off
6. Touch 4 down: Switch game/video mode

Parameter

Frequency: 100HZ-10KHZ
Charging port: Type-C
Effective distance: 15-20 M
Speaker: 8MM
Input Current: 5V-1A
Output Current: 5V-1A
Impedance: 32Ω
Wireless Protocol HSP/HFP/A2DP/AVCP/SPP

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.