

LED Tail Lights


WD-2036B user manual

running light +brake light +turn signal
行车 + 刹车 + 转向



功能切换按钮
Function switch button

play and plug
black -negative
electrode
Yellow-singal
White -reversing
Green-Running light
Red-brake light
Brown-fog lamp



Function switch mode: Turn on the running light and double flash button to switch the following modes. Red cursor2. Yellow cursor3. Red water4. Yellow water 5. Red light with-out water 6. Yellow light no running water Turn on the running light and press for more than 5 seconds to flash the light to enter whether the driving dynam-ic selection

1. Plug - Open double flash according to the original car function, red double flash
2. Unplug - the connector is connected to the high brake light and the double flashing and separate steering function are consistent

BT mode:

1:You can download the RGB controller from the app store, or scan the QR code below to download it.



2: Open the app, select Bluetooth device, select Scan, and the device WD-2036B will be displayed. Click Connect. If the connection is successful, the car lights will flash quickly and then turn off. If the

connection is not successful, please power on the car lights again.

3:After successful connection, the color of the light can be adjusted as needed.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is

subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.