

connect to smart device

Turn on the unit and switch on your mobile Smart, then search for the speaker model name and pair the device.

Once device is paired, Wireless will automatically on subsequently



- 1.OFF/ON: To turn ON/OFF the speaker.
 - 2.DC 5V: Plug the Micro USB cable to the speaker and connect other end USB port to the power source.
(DC 5V)Aux: Audio input jack when connect Enable the sound source connection active devices (PC, digital media player, mobile phones and other audio-visual products).
 - 3.USB slot: Used to read the song files in FAT32 format with maximum size of 32GB
 - 4.TF slot: Used to read the song files in FAT32 format with maximum size of 32GB
 - 5.Play/Pause: Under USB/TF/Smart mode, short press for play and pause;
 - 6.M: To change mode during USB/TF, Smart, FM mode.
 - 7.PREVNOL-:USB/TF/Wireless/FM mode: Swipe left to move previous FM channel / track.
Swipe left and long press to decrease the volume
 - 8.NEXTNOL+:USB/TF/Smart/FM mode: Swipe right to move next FM channel / track.
Swipe right and long press to increase the volume
- NOTE: If FM mode reception is not good, connect a Micro USB cable for better FM reception.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.