


TUBE AMPLIFIER


Operating Instructions



- We greatly appreciate your purchase of the product.
- Before attempting to connect, operate or adjust this product, please read these instructions completely.

Safety Precautions

- A** Do not open the cover, re-fix or touch the inner parts.
No user-serviceable parts inside, Refer servicing to qualified service personnel.
- B** Protect voltage line avoid high pressure and stamp on, do not pull, push excessively.
- C** Please put on this unit in a cool well ventilated area. Avoid direct sunshine and direct exposure to heat or keep near a heater.
Do not operate in a sealed box and be sure to have enough room for heat exchange.
- D** Avoid covering vents. Closing up the vents will increase the temperature in the unit and will damage the unit.
- E** Avoid metals dropping in the unit, like needles, hairpins, coins, etc as this could cause a short and damage the unit.
- F** Ensure to set the line voltage 230V 50Hz if you are not sure of the type of power supply, consult your appliance dealer or local power company.



For MAINS powered apparatus and for apparatus producing internal voltages greater than 35V(peak) a.c. or d.c., having no protection against splashing water according to annex A, the instructions for use shall state that the apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on or near the Apparatus

Instructions to ensure correct and safe installation and interconnection of the apparatus in multimedia systems, The mains plug is used as the disconnect device, the disconnect device shall be readily operable.

● TECHNICAL PARAMETERS

Rated Power: 40Wx2(4Ω)

Power Dissipation: 100W

Input power: AC 110V/60Hz

Input Impedance: 47KΩ

Input Sensitivity: 500MV

S/N Ratio ≥ 80dB

THD ≤ 0.5%


Treble: ±10dB

Bass: ±10dB

Frequency Response: 20Hz-20KHz


Tube: 2 pairs of 6J1/6K4

● BLUETOOTH OPERATION




1. Open the power switch, Revolve the 'INPUT' knob until :USB/BT:
No usb drive status
2. Ensure Bluetooth ability is activated on your device and search for Bluetooth network named :
' Hi-Fi ' and connect.
3. No password is required for connecting
4. When connected successfully, Begin playing music by selecting a music file.

● PASSIVE SPEAKER CONNECTION




Connecting passive speaker to passive speaker Output
Terminal by speaker cable properly

● Front Panel



- ① Power
- ② Headphone jack
- ③ Input signal
- ④ PREV
- ⑤ NEXT
- ⑥ Display mode
- ⑦ Display screen
- ⑧ BASS Knob
- ⑨ TREBLE Knob
- ⑩ Master volume control

● REAR PANEL



- ① Bluetooth antenna
- ② Active Subwoofer Output
- ③ Optical Input
- ④ Coaxial Input
- ⑤ CD Input
- ⑥ DVD Input
- ⑦ Usb jack
- ⑧ Right speaker Output Terminals
- ⑨ Left speaker Output Terminals
- ⑩ Power supply

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment