


User Manual
Magnetic wireless charging power bank
Model : BJCDB001



Operating instructions:

1. Press the power button to display the remaining power
2. Power input and output: Use the power cable to connect the power adapter to charge the power bank, connect the power bank to charge the device to be charged through the power cable, or use the wireless charger to charge the mobile phone

Technical parameters:

Battery type : Polymer battery
Executive standard: GB/T35590:2017
Capacity : 4000mAh
Input: 5V/3A
Output:5V/3A
Wireless output: 5W(Max)
Size:;
Weight:

How to charge for power bank

1. Use the Type C charging cable to charge for power bank.
2. It is recommended to connect the power adaptor to charge for power bank.
3. It can be connected to the USB port of the computer to charge for power bank.
4. After press the power button ,the LED power indicator of the power bank is white color.
5. While charging, the white LED power indicator of the power bank blinks successively.
6. When fully charged, the LED power indicator of the power bank is steady with white color.
7. 4pcs LED power indicator lights correspond to 25%, 50%, 75%, and 100% of the remaining power battery level of the power bank .

Charging for iWatch or mobile phone

1. Mobile power is used to charge mobile devices
2. Connecting power bank and mobile phone with power cable ,mobile phone is charged by power bank automatically.
3. Put the mobile phone which supports wireless function on power bank wireless charging area,then press the power button and wait for around 8 seconds, the power bank will be automatically charged for mobile phone.
4. While charging for iWatch or mobile phone, the LED power indicator lights up with white color.
5. After iWatch or mobile phone is fully charged, the power bank will be shutdown automatically within 30 seconds after disconnecting.

Note:

1. The charging time of this power bank is about 3-4 hours. The specific time is subject to the actual situation.
2. If the power bank cannot be charged or the iWatch or mobile phone cannot be charged by power bank, please check if the connection cable is normal and firm, the charging port accessory is suitable or not. It is recommended to use a regular brand power adapter to charge for power bank .
3. There is a conversion rate of power bank, so the capacity of power bank is not equal to the rechargeable capacity.
4. If the power bank cannot be turned on for short circuit protection due to improper operation, please charge the power bank to activate it.

Safety Information:

Warning: Failure to follow these safety instructions may result in fire, electric shock, damage or other injury.

1. Please try to keep the storage temperature of the product between 10-35°C.
2. Do not fall, do not disassemble or puncture, repair the power bank by yourself.
3. Do not expose the power bank in fire, high temperature or water.
4. Stop using the power bank if you find any abnormal phenomena such as expansion or expansion of the charged device.
5. This device is not suitable for using by persons with immature physical, perceptual and mental abilities (including children), nor by persons lacking relevant experience and knowledge, unless supervised and guided by someone who is professionally responsible for their personal safety. Please control children to ensure that they do not use this device as a toy.
6. Do not leave the product in the car for a long time, especially when parked in the sun.
7. Do not put foreign bodies into the product interface.
8. Please charge your power bank at least every three months.

The above information is for reference only and is subject to change without prior notice.

List of parts:

1. Power bank *1
- 2.Type C charging cable *1
3. User manual *1

FCC WARNING STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Portable RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 0 centimeters from the device surface at all times, except for non-repetitive patterns with transient timeintervals in the order of a second. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498