

尺寸: 100*100mm
材质: 100克双胶纸
双面印刷

user's manual

MCHOSE

G9/ G9 Pro Wireless & G9 Wired Gaming Headset

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

Product Overview PART 1

G9/ G9 Pro Wireless

G9 Wired

2.4G Connection G9/ G9 Pro Wireless PART 3

Wireless Connection G9/ G9 Pro Wireless PART 4

Note: The headset disconnects when out of range and automatically reconnects when the device is back in range. If no device reconnects within 5 minutes, the headset will automatically turn off.

Sound Card Mode PART 5

1. When the headset is powered on, insert the cable into the headset and connect it to the computer. The headset will automatically switch to sound card mode.
2. You can double press the [G Key] to cycle through [Adapter Mode] / [Wireless Mode] / [Sound Card Mode].
3. In 2.4G and Wireless modes, you can insert the charging cable to charge while playing.

Headset Charging PART 6

SPECIFICATIONS

Speaker: Ø50mm
Speaker Impedance: 32.Ω±15%
Frequency Response Range: 20Hz-20KHz
MIC Sensitivity: -36dB±3dB/1KHz (single unit)
SPK Sensitivity: 120±3dB/1KHz (single unit)
Charging Time: About 3 hours

Note: This device has been tested and complies with the limits for Class B digital devices as set forth in Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the responsible party for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTIONS

1. It is recommended to charge the keyboard only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the keyboard.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the keyboard away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).

WARRANTY CARD

Thank you for purchasing our product. Please contact us if there are any quality issues within the warranty period. Please provide this warranty card so we can provide comprehensive after-sales service.

Product Items: _____ Customer Name: _____

Serial No.: _____ Contact Address: _____

Purchase Date: _____ TEL / E-mail: _____

Purchase Channel: _____ Postcode: _____