

## Instructions

The upgrade remote controller (3 in 1) for the power inverter.  
Wireless Remote Control, Wired Remote Control, and Remote Display  
Function: Remote control the inverter, easy to turn inverter ON or OFF,  
and monitor the inverter's working status.

### ■ Wireless Remote Control Operation:

1. Plug the remote module into inverter's remote port.
  2. Use the remote controller to turn ON/OFF power inverter
- Note: Ensure the inverter switch is OFF when using the remote control.

Operation Mode	Status
Short press in screen-off mode	Light up the screen
Short press in screen-on mode	Switching between the remote controller's internal battery voltage/level and the battery system voltage/level
Long press in screen-on mode (2 seconds)	Turn ON Power Inverter
Long press in screen-on mode (2 seconds)	Turn OFF Power Inverter

Remote Module

Wireless control distance :  
50m-100m (164ft-328ft)



Remote LCD Display



## Instructions

The upgrade remote controller (3 in 1) for the power inverter.  
Wireless Remote Control, Wired Remote Control, and Remote Display  
Function: Remote control the inverter, easy to turn inverter ON or OFF,  
and monitor the inverter's working status.

### ■ Wired Remote Control Operation:

1. Connect the power inverter to remote controller using provided remote wire.
  2. Use the remote controller to turn ON/OFF power inverter.
- Note: Ensure the inverter switch is OFF when using the remote control.

Operation Mode	Status
Short press in screen-off mode	Light up the screen
Short press in screen-on mode	Switching between the remote controller's internal battery voltage/level and the battery system voltage/level
Long press in screen-on mode (2 seconds)	Turn ON Power Inverter
Long press in screen-on mode (2 seconds)	Turn OFF Power Inverter



**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.