

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

WIFI CAMERA

Quickbooks for Android and iOS

the power delivered by the charger must be between min

[5] Watts required by the radio equipment, and max [10]

Watts in order to achieve the maximum charging speed.

Operation

1.Download APP

Ways one:Scan QR code.



Android



iOS

Tips two :Search "iCSee" in the App store or Googleplayand download.

2.Power on

Install TF Card ,Then power on.

3.Camera configuration

*User login

- 01.open the app "iCSee" ,choose the "login(picturel)(If without user name, please register first).
- 02.After Click "+

- 03.Enter to"Add device " ,please input WiFirouter password,TheThen confirm
- 04.After ycu hear a camera voice "connect success-fully" ,willenter to "set pwd" Then confirm .
- 05.After “confirm "will enter to "pick a name"
- 06.After click "save" will enter to video

*Temporary user

- Don't need register .Add the device then check video .(Theinformation only kept in you mobile phone .If you change the-mobile phone ,must restart download the app and adddevice .This rmodel don't support alarm push).
- .OpenApp"iCSee" ,choose temporary visit.
- .click the upperright “+” .,according to promote tips ,finishadd camera.
- "Please refer to the "Usermod-el-02/03"introduce operation.

Q: How to store a videp camera?

A:Currently, the Home Robot camera supports FAT32Gformat Class6,Class10TF Card, max supports 128G. Whenthe TF Card is full, it will delete earlier video automaticallyand loop recording.

Q: The camera be offline, how to do?

A: Check the power and wifi.

Restart power on and restart the camera.

Reconfigure the camera.

Check the home broadband network.

Q: How to switch netwprk environment?

A: When using in the new network environment, please longpress the reset button (\$ET) for 6 seconds release the button.It means that restored to factory setting successfully. Thenyou can start to connect network configuration again.

Directions

App and device firmwire will have newupdate ir-regularly,youcould upgrade itonline at app set-ting,instructions are forreference only.