



# WiFi MANUAL



**Viidure**




## PRECAUTIONS BEFORE USING THIS CAMERA

- ① *Please use the original car charger provided to avoid fault or incompatibility.* The dash cam battery is just to maintain and save settings. It should be connected to the car charger to get constantly powered, if the power is interrupted to the unit, it will shut down.
- ② *Please "Reset" dash cam or reinsert & format if "SD Card error"*
- ③ *If Any problem, please feel free ask our aftersales team.*
- ④ *The Dash Cam's wifi is for app control only. It's do not support network or remote monitoring,*

# How to Using Wifi&APP

## Step 1. Download APP:

Please Search in Google Play or Apple Store for free APP **"Viidure"** to download APP



**Or Scran the QR code to download**



## Step 2. Turn on the D50's WiFi:

**Method 1:** Long Press on the UP button in working status

**Method 2:** Open it in the Menu setting.

- ① Stop recording;
- ② Long press on the MENU button;
- ③ Use UP and Down find the **WiFi&APP** option, and turn it on;

## WiFi Interface




**WiFi Name: D50 \*\*\*\***

**Default Password:12345678**

### Step 3. Connecting WiFi

Turn on the WiFi connection settings on the mobile phone, and search the WiFi name “ **D50 \*\*\*\***”, enter and input password to connect (password:**12345678**).

Please Note that it's turn on “WLAN” to connect WiFi, not “Bluetooth”.






## IMPORTANT NOTES

The WiFi can not be used for scanning web

By WiFi, you can download the camera's file to your Phone.

### Step 4. Operate the APP

By the APP you can download the video from the camera and you can make general settings for the Camera



After WiFi is connected, operate the APP

**When you connect the WiFi and operate the APP, then you can not operate dash cam by the button.**



## PRECAUCIONES ANTES DE UTILIZAR ESTA CÁMARA

- ① Utilice el cargador de automóvil original proporcionado para evitar fallas o incompatibilidad. La batería de la cámara del tablero es solo para mantener y guardar configuraciones. Debe conectarse al cargador del automóvil para recibir energía constantemente; si se interrumpe la alimentación de la unidad, se apagará.
- ② *"Reinicie" la cámara del tablero o vuelva a insertarla y formatéela si aparece un error en la tarjeta SD.*
- ③ *Si tiene algún problema, no dude en consultar con nuestro equipo de posventa.*
- ④ *El wifi de la Dash Cam es solo para control de aplicaciones. No es compatible monitoreo remoto o de red,*

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.