


APP usage instructions



Style mode



Mic mode

Scroll the selection mode

Select sound source

4-style thym

Change the sensitivity of MIC

Operation instructions

Bluetooth RGB light with controller


Parameter Description:

1. Input voltage: 5V 12V 24V
2. The app supports Android 4.4 and above and IOS 11.0 or above



APP instructions

1. Please scan the QR code on the right to download and install the mobile control app. And turn on the Bluetooth function of the phone and allow relevant access permissions.
2. Turn on the light strip power, and the app will automatically scan and add nearby light strip devices that can be connected



Attention:

- 1: Please ensure that the input power supply matches the voltage of the light strip used. Using the wrong input power supply may cause damage to the controller or light strip.
- 2: If the app cannot connect to the light strip, please check if the Bluetooth function of the phone is turned on and if the light strip is being connected to another phone. The app can be restarted or the restart light can be tested with compensation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.