Band Edge(Hopping) NVNT 2-DH1 2402MHz Hopping Ref

Band Edge(Hopping) NVNT 2-DH1 2402MHz Hopping Emission



Band Edge(Hopping) NVNT 2-DH1 2480MHz Hopping Ref



Band Edge(Hopping) NVNT 2-DH1 2480MHz Hopping Emission



Band Edge(Hopping) NVNT 3-DH1 2402MHz Hopping Ref

Band Edge(Hopping) NVNT 3-DH1 2402MHz Hopping Emission



Band Edge(Hopping) NVNT 3-DH1 2480MHz Hopping Ref

Band Edge(Hopping) NVNT 3-DH1 2480MHz Hopping Emission



10. 20 dB Bandwidth

10.1 Block Diagram Of Test Setup



10.2 Limit

N/A

10.3 Test procedure

1. Set RBW = 30kHz.
2. Set the video bandwidth (VBW) ≥ 3 x RBW.
3. Detector = Peak.
4. Trace mode = max hold.
5. Sweep = auto couple.
6. Allow the trace to stabilize.
7. Measure the maximum width of the emission that is constrained by the frequencies associated with the two outermost amplitude points (upper and lower frequencies) that are attenuated by 6 dB relative to the maximum level measured in the fundamental emission.

10.4 Test Result

Temperature:	26 ℃	Relative Humidity:	54%RH
Pressure:	101KPa	Test Voltage :	DC 3.8V

Condition	Mode	Frequency (MHz)	-20dB Bandwidth (MHz)	Verdict
NVNT	1-DH1	2402	0.879	Pass
NVNT	1-DH1	2441	0.849	Pass
NVNT	1-DH1	2480	0.884	Pass
NVNT	2-DH1	2402	1.217	Pass
NVNT	2-DH1	2441	1.228	Pass
NVNT	2-DH1	2480	1.227	Pass
NVNT	3-DH1	2402	1.233	Pass
NVNT	3-DH1	2441	1.218	Pass
NVNT	3-DH1	2480	1.240	Pass

Test Graphs
-20dB Bandwidth NVNT 1-DH1 2402MHz

-20dB Bandwidth NVNT 1-DH1 2441MHz

-20dB Bandwidth NVNT 1-DH1 2480MHz



-20dB Bandwidth NVNT 2-DH1 2402MHz

-20dB Bandwidth NVNT 2-DH1 2441MHz

-20dB Bandwidth NVNT 2-DH1 2480MHz

-20dB Bandwidth NVNT 3-DH1 2402MHz

-20dB Bandwidth NVNT 3-DH1 2441MHz

-20dB Bandwidth NVNT 3-DH1 2480MHz

11. Maximum Peak Output Power

11.1 Block Diagram Of Test Setup



11.2 Limit

FCC Part15 (15.247) , Subpart C				
Section	**Test Item**	**Limit**	**Frequency Range (MHz)**	**Result**
15.247(b)(1)	Peak Output Power	0.125 watt or 21dBm	2400-2483.5	PASS

11.3 Test procedure

1. Remove the antenna from the EUT and then connect a low RF cable from the antenna port to the spectrum.
2. Set the spectrum analyzer: RBW = 2MHz. VBW = 6MHz. Sweep = auto; Detector Function = Peak.
3. Keep the EUT in transmitting at lowest, medium and highest channel individually. Record the max value.

11.4 Test Result

Temperature:	26 ℃	Relative Humidity:	54%RH
Pressure:	101KPa	Test Voltage :	DC 3.8V

Condition	Mode	Frequency (MHz)	Conducted Power (dBm)	Limit (dBm)	Verdict
NVNT	1-DH1	2402	-0.05	21	Pass
NVNT	1-DH1	2441	0.63	21	Pass
NVNT	1-DH1	2480	1.13	21	Pass
NVNT	2-DH1	2402	0.87	21	Pass
NVNT	2-DH1	2441	1.47	21	Pass
NVNT	2-DH1	2480	1.90	21	Pass
NVNT	3-DH1	2402	1.44	21	Pass
NVNT	3-DH1	2441	2.00	21	Pass
NVNT	3-DH1	2480	2.41	21	Pass

Test Graphs
Power NVNT 1-DH1 2402MHz

Power NVNT 1-DH1 2441MHz



Power NVNT 1-DH1 2480MHz



Power NVNT 2-DH1 2402MHz



Power NVNT 2-DH1 2441MHz



Power NVNT 2-DH1 2480MHz

Power NVNT 3-DH1 2402MHz



Power NVNT 3-DH1 2441MHz

Power NVNT 3-DH1 2480MHz


12. Hopping Channel Separation

12.1 Block Diagram Of Test Setup



12.2 Limit

Frequency hopping systems shall have hopping channel carrier frequencies separated by a minimum of 25 kHz or the 20 dB bandwidth of the hopping channel, whichever is greater. Alternatively, frequency hopping systems operating in the 2400-2483.5 MHz band may have hopping channel carrier frequencies that are separated by 25 kHz or two-thirds of the 20 dB bandwidth of the hopping channel, whichever is greater, provided the systems operate with an output power no greater than 0.125W.

12.3 Test procedure

1. Remove the antenna from the EUT and then connect a low RF cable from the antenna port to the spectrum.
2. Set the spectrum analyzer: RBW = 30kHz. VBW = 100kHz , Span = 2.0MHz. Sweep = auto; Detector Function = Peak. Trace = Max hold.
3. Allow the trace to stabilize. Use the marker-delta function to determine the separation between the peaks of the adjacent channels. The limit is specified in one of the subparagraphs of this Section Submit this plot.

12.4 Test Result

Mode	Test Channel	Separation (MHz)	Limit(MHz)	Result
1-DH1	Low	1.000	0.586	PASS
1-DH1	Middle	0.998	0.344	PASS
1-DH1	High	1.000	0.589	PASS
2-DH1	Low	1.000	0.811	PASS
2-DH1	Middle	0.996	0.819	PASS
2-DH1	High	1.000	0.818	PASS
3-DH1	Low	1.004	0.822	PASS
3-DH1	Middle	1.002	0.812	PASS
3-DH1	High	1.002	0.827	PASS

Test Graphs
CFS NVNT 1-DH1 2402MHz

CFS NVNT 1-DH1 2441MHz

CFS NVNT 1-DH1 2480MHz

CFS NVNT 2-DH1 2402MHz



CFS NVNT 2-DH1 2441MHz



CFS NVNT 2-DH1 2480MHz



CFS NVNT 3-DH1 2402MHz



CFS NVNT 3-DH1 2441MHz



CFS NVNT 3-DH1 2480MHz



13. Number Of Hopping Frequency

13.1 Block Diagram Of Test Setup



13.2 Limit

Frequency hopping systems in the 2400-2483.5 MHz band shall use at least 15 channels.

13.3 Test procedure

1. Remove the antenna from the EUT and then connect a low RF cable from the antenna port to the spectrum.

2. Set the spectrum analyzer: RBW = 100kHz. VBW = 300kHz. Sweep = auto; Detector Function = Peak. Trace = Max hold.

3. Allow the trace to stabilize. It may prove necessary to break the span up to sections. in order to clearly show all of the hopping frequencies. The limit is specified in one of the subparagraphs of this Section.

4. Set the spectrum analyzer: Start Frequency = 2.4GHz, Stop Frequency = 2.4835GHz. Sweep=auto;

13.4 Test Result

Condition	Mode	Hopping Number	Limit	Verdict
NVNT	1-DH1	79	15	Pass
NVNT	2-DH1	79	15	Pass
NVNT	3-DH1	79	15	Pass

Test Graphs
Hopping No. NVNT 1-DH1 2441MHz



Hopping No. NVNT 2-DH1 2441MHz



Hopping No. NVNT 3-DH1 2441MHz



14. Dwell Time

14.1 Block Diagram Of Test Setup



14.2 Limit

Frequency hopping systems in the 2400-2483.5 MHz band shall use at least 15 channels. The average time of occupancy on any channel shall not be greater than 0.4 seconds within a period of 0.4 seconds multiplied by the number of hopping channels employed. Frequency hopping systems may avoid or suppress transmissions on a particular hopping frequency provided that a minimum of 15 channels are used.

14.3 Test procedure

1. Remove the antenna from the EUT and then connect a low RF cable from the antenna port to the spectrum.
2. Set spectrum analyzer span = 0. Centred on a hopping channel;
3. Set RBW = 1MHz and VBW = 3MHz.Sweep = as necessary to capture the entire dwell time per hopping channel. Set the EUT for DH5, DH3 and DH1 packet transmitting.
4. Use the marker-delta function to determine the dwell time. If this value varies with different modes of operation (e.g.. data rate. modulation format. etc.). repeat this test for each variation. The limit is specified in one of the subparagraphs of this Section. Submit this plot(s).

14.4 Test Result

Mode	Frequency (MHz)	Pulse Time (ms)	Total Dwell Time (ms)	Burst Count	Period Time (ms)	Limit (ms)	Verdict
1-DH1	2441	0.382	121.094	317	31600	400	Pass
1-DH3	2441	1.637	255.372	156	31600	400	Pass
1-DH5	2441	2.886	352.092	122	31600	400	Pass
2-DH1	2441	0.391	124.338	318	31600	400	Pass
2-DH3	2441	1.642	249.584	152	31600	400	Pass
2-DH5	2441	2.886	308.802	107	31600	400	Pass
3-DH1	2441	0.391	124.729	319	31600	400	Pass
3-DH3	2441	1.641	269.124	164	31600	400	Pass
3-DH5	2441	2.894	332.81	115	31600	400	Pass

Note: Total Dwell Time (ms) = Pulse Time (ms)*Burst Count

Test Graphs
Dwell NVNT 1-DH1 2441MHz One Burst

Dwell NVNT 1-DH1 2441MHz Accumulated


Dwell NVNT 1-DH3 2441MHz One Burst



Dwell NVNT 1-DH3 2441MHz Accumulated



Dwell NVNT 1-DH5 2441MHz One Burst



Dwell NVNT 1-DH5 2441MHz Accumulated



Dwell NVNT 2-DH1 2441MHz One Burst



Dwell NVNT 2-DH1 2441MHz Accumulated



Dwell NVNT 2-DH3 2441MHz One Burst



Dwell NVNT 2-DH3 2441MHz Accumulated



Dwell NVNT 2-DH5 2441MHz One Burst



Dwell NVNT 2-DH5 2441MHz Accumulated



Dwell NVNT 3-DH1 2441MHz One Burst



Dwell NVNT 3-DH1 2441MHz Accumulated



Dwell NVNT 3-DH3 2441MHz One Burst



Dwell NVNT 3-DH3 2441MHz Accumulated



Dwell NVNT 3-DH5 2441MHz One Burst



Dwell NVNT 3-DH5 2441MHz Accumulated



15. Antenna Requirement

15.1 Limit

15.203 requirement: For intentional device, according to 15.203: an intentional radiator shall be designed to ensure that no antenna other than that furnished by the responsible party shall be used with the device.

15.2 Test Result

The EUT antenna is Internal antenna, fulfill the requirement of this section.

16. EUT Photographs

EUT Photo



NOTE: Appendix-Photographs Of EUT Constructional Details

17. EUT Test Setup Photographs

Conducted emissions

Radiated Measurement Photos



STATEMENT

1. The equipment lists are traceable to the national reference standards.

2. The test report can not be partially copied unless prior written approval is issued from our lab.

3. The test report is invalid without the "special seal for inspection and testing".

4. The test report is invalid without the signature of the approver.

5. The test process and test result is only related to the Unit Under Test.

6. Sample information is provided by the client and the laboratory is not responsible for its authenticity.

7. The quality system of our laboratory is in accordance with ISO/IEC17025.

8. If there is any objection to this test report, the client should inform issuing laboratory within 15 days from the date of receiving test report.

Address:
1-2/F., Building B, Pengzhou Industrial Park, No.158, Fuyuan 1st Road, Zhancheng, Fuhai Subdistrict, Bao'an District, Shenzhen, Guangdong, China

TEL: 400-788-9558

P.C.: 518103

FAX: 0755-33229357

Website: http://www.chnbctc.com

Consultation E-mail: bctc@bctc-lab.com.cn

Complaint/Advice E-mail: advice@bctc-lab.com.cn

※※※※※ END ※※※※※