


ANCwear®

OPEN EAR HEADPHONES

User Manual




Version 1.0

Please read the instruction carefully before use

Contents


Headphone Controls	01
ON/OFF	02
Pairing	03
How to Wear	04
Volume	05
Operating Instruction	06
Charging Tips	07
Storage and Maintenance	08

Headphone Controls



ON/OFF _____

ON/OFF



Turn on the headphones:

Press and hold the "+" Button until the LED Indicator flashes blue.

*the headphones will say: "power on"


Turn off the headphones:

Press and hold the "+" Button until the LED Indicator flashes blue.

*the headphones will say: "Power off"


Pairing

1. Start with the headphone turned off.
2. Press and hold the "+" Button for 1 to 3 seconds until the LED Indicator flashes red and blue alternately.



3. Open your (mobile phone / computer) device's Bluetooth settings and select "EK-OH**", Click the device to pair and connect.


How to Wear



Pick up the headphones, bring them behind the back of the base of your neck, position the earhooks on your ears, then enjoy your music!

*Wearing your headphones the wrong way could cause discomfort. The transducers should rest in front of your ears.

Volume



How to change volume:

While your audio is playing, adjust headphone volume by pushing either the Volume + or Volume - buttons.



*A “beep” will sound when the volume is at its max.

 *Listening with headphones at high volume may affect your hearing and the audio will be distorted.

Operating Instruction

Function	Operation	Indicator
On	Long press on key for 1-3 seconds	Light is on
Off	Long press on key for 1-3 seconds	Light is off
Increase volume	Click the "+" button	"du" beeps when volume is increased
Reduce volume	Click the "-" button	"du" beeps when volume is increased
Next/Previous	Double click "+"/"" in the music state to switch the next/previous song	/
Pause/Play	During music playback, press and hold the "+" button for 1 second to pause/play music.	/
With phone access	Voice announcement of caller's number	blue light flashing
Answer the phone	Click the "+" button when an incoming call comes in.	Blue light 5s slow flash
Decline the call	During a call, press and hold the "+" button for 1s.	/
Refuse to receive	On an incoming call, press and hold the "+" button for 1s.	/
Answer the second incoming call while on a call	Click the "+" button to hang up the first call and answer the second call; Double-tap the "+" key to answer the second call and hold the first call	/

Charging Tips



The first use of the headset must be fully charged to the battery. In use, if only the red light flashes and the voice prompting low power, that the battery is low, then you need to charge the headset. The charging cable should be connected to the headset's magnetic charging port, about 2 hours to fill. Charging status indicator flashing breathing light, full charge often blue light.

Note: Magnetic charging has a positive and negative pole corresponds to each other adsorption can be charged normally, mustual repulsion can not be charged or even cause a short circuit.

Storage and Maintenance

- Store the headphones in a cool, dry place. The working temperature should be 0~45°C(32~113°F). Working in a cold/hot temperature, highly humid area, or low air pressure environment may reduce the battery life.
- Keep the product away from heat sources, direct sunlight, combustible gas or other liquids.
- Keeping the charging port dry before connecting to the charger will reduce the risk of damage.
- The headset can not soak seawater/salt water for a long time, filling the magnetic suction part is easy to corrode.
- Clean the headphones with a soft dry cloth.
- Do not charge right after exercising, in case there's sweat inside the charging port, which could lead to circuit burning while charging.
- If not used for a long time, please at least once a month full of electricity.

Warning

To avoid the risk of explosion, fire, or leakage from toxic chemicals, please do not disassemble the product or replace, deform, or mutilate the battery.

Warranty

One year warranty for manufacturing defects.

Any quality defects, contact us, you will get A Full Refund or A Free Replacement!



ANCwear®

Dear Customer,

We want to prosper and know this will be achieved best by providing the quality experience to our valued customers like you. Please feel free to contact ANCwear service team and always here for you.

Yours sincerely,
ANCwear Service Team

Customer Support:



Email:

Support_US@ancwear.com

Support_UK@ancwear.com

Support_EU@ancwear.com

Support_Global@ancwear.com

Official Website: <https://www.ancwear.com>



@ANCwear fit



@ancwear



@ANCwear

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.