

User's Guide

Power on/off:

1. ON/OFF: power switch; ON means open, OFF means close
2. Long press the power switch to turn on/off

Wireless connections:

After the product is turned on, turn on the wireless function of the mobile device (mobile phone, computer, etc.), search for the wireless device, click manually, the device will automatically pair and connect, and the speaker will make a sound if the connection is successful. There is no sound. Just check whether the wireless icon on the mobile device shows that the connection is successful.

[Devices that have been paired successfully will automatically connect next time they are turned on] If the connection is still not successful, please delete all connected devices on the mobile device and re-match, or restart the mobile device.

Volume adjustment/switching songs

1. Long press to adjust the volume/or short press to adjust the volume
2. Long press to switch songs/or short press to switch songs

Radio/mode switch

If the product has an M button, the product has a radio function. If there is no M button, the product does not have a radio function. 1. Long press to switch radio mode/or short press to switch radio mode

Volume adjustment/switching radio stations

1. Long press to adjust the radio volume/or short press to adjust the radio volume
2. Long press to switch radio stations/or short press to switch radio stations

[Long press the M button to return to music mode/or short press the M button to return to music mode]

Pause/play/answer/hang up

Long press/or short press

TF card mode [If the product has a TF card slot, it supports TF card mode; if it does not have a card slot, it does not support TF card mode]

(The music in the TF card memory card must be in MP3 format to support music playback)

RGB lighting mode

If the product has RGB lights, it supports light switching. If it does not have RGB lights, there is no light mode.

1. Long press/or short press (light button) to switch light mode

USB mode (the product supports USB mod

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF exposure:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.