

VISTATECH

Sonic Radiance
Multi-Functional Bug Fan
With wireless speaker and LED lamp

OPERATING INSTRUCTIONS:

1. Insert 3 x AAA batteries into the base or use the USB type C cable.

(USB type C cable included).



2. Turn on the switch.

"" represents the fan.

"" represents the light.

"+" means increase the volume.

"-" means decrease the volume.

3. The wireless speaker:



The speaker can only be controlled by a phone. When you turn on the device, the bluetooth will automatically activate. You can search for the bluetooth named "Fanled" on your phone to connect directly.

4. Place the device on the table close to the food.

5. Enjoy your meal free of flies.

Caution:

All batteries must be same type and size.

Do not mix old and new batteries.

If battery contents are leaking, discontinue use and discard.

Remove exhausted batteries.

Remove batteries if the item is not going to be used for an extended period of time.

WARNING

Power Supply Cable

Always use only the factory supplied USB type C cable that came with this device. Do not use any other USB type C cable.

Use of another USB type C cable can result in overheating, melting, fire, personal injury or death from fire or damage to your device.

Printed in China

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The distance between user and products should be no less than 20cm.