



Transtek LLC

---

**Transtek LLC**

**Traffic Series**

**CB-SL12V-00 Data Sheet**

---



## Product profile

CB-SL12V-00 is an independent controller which is developed by LYAN. Control intelligent traffic display equipment, pedestrian right-of-way display, highway fog light..... With powerful processing capacity, super stability.

## Parameters

Load Capacity	2 output	12V control LED
Input	I0	button switch
Frequency Range:	903.529MHz~926.471MHz	
Channel:	16	In the range of frequency, it is divided into 16 channels according to the interval of 1.529412MHz

# Hardware Introduction


## Front View





Introduction		
No.	Item	
1	Initiate start button	start display status
2	Net Address	Press to display the current signal channel, Rotate to left and right to adjust the channel (1-16); double press to save the current channel.
3	Time	Press to display current time, Rotate to left and right to adjust the seconds (0-99) double press to save the time.
4	Flash Pattern	Press to display current display pattern, Rotate to left and right to adjust the seconds (1-5) double press to save the display pattern.
5		

---





This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.ct.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

---