

If the device has been left unused for over 6 months, it needs to be fully charged before using.

CC Statement

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Check the E-labels from Settings » Certifications

CAUTION

		IT	NL	SK	LV	LT
		DK	IE	BG	RO	MT
		ES	PT	FR	DE	EE
FI	AT	SE	PL	BE	LU	HR
HU	CZ	CY	SI	GB	GR	


CE

This equipment complies with Directive 2014/53/EU radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by European Union market (France).

The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: 2BFP0-P053 For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the device minimum of 10 mm from the body .

Diagram illustrating the front view of the PDA with the following components labeled:

- Printer Paper Cabin
- NFC Recognition Area
- Front Camera(optional)
- Power Key
- Charging Interface
- Indicators
- Magnetic Card Reader
- Screen
- Keyboard
- IC Card Slot



- 1.**Printer Paper Cabin:** to insert printing paper
- 2.**NFC Recognition Area:** to recognize NFC card
- 3.**Power key:** long press to power on/off; short press to activate or shutdown the screen
- 4.**Charging Interface:** to insert USB -C plug of charger
- 5.**Magnetic Card Reader:** to swipe magnetic Card
- 6.**Indicators:** indicating terminal charging status
- 7.**Screen:** display and touch operation
- 8.**Keyboard:** secured PINPad
- 9.**IC Card Slot:** to swipe IC card
- 10.**Front/Rear Camera:** scanning and photography
- 11.**Speaker:** to play sound
- 12.**Charging Base Connector(optional):** to connect with the charging base
- 13.**Battery Cabin:** to place and protect the battery

Operation System	Android OS
CPU	Qualcomm Quad-Core
Memory	1G RAM, 8G ROM/ 2G RAM, 32G ROM
Screen	4" LCD
Camera	Front Camera: 2M FF(Optional), Rear Camera: 0.3M FF, 2M FF(Optional)
BT	BT5.0
Wi-Fi	2.4G/5G, 802.11 a/b/g/n/ac
NFC	13.56MHz
Magnetic Card Reader	Track 1/2/3
IC Card Reader	ISO7816, Encrypted Head

Note: Clean the printer regularly

- Do not place the terminal in extremely hot or cold conditions.
- Do not place terminal together with computer disc, credit card, travel card or any other magnetic items; otherwise, the information stored in magnetic cards will be affected.
- Do not place the terminal in fire.
- Do not disassemble the terminal or any accessories by yourself.
- Please use a moist and anti-static cloth to clean the terminal screen.
- Warning: Please replace the batteries with the same type and rating to avoid battery explosion.
- Do not expose the battery in strong direct sunlight, near heat sources or any similar conditions.
- Please recycle or dispose of old, weak, or worn batteries in accordance with local, regional, or national law or regulation.
- Do not use detergent with chemical or scrub particle which may damage the terminal body or screen.
- Please keep the terminal in a safe place and avoid crush or squeeze that may cause a damage on screen or camera.
- When the user use the third party's root tool or update with unauthorized operation system, it will bring risk to the normal operation system.
- The maximum operating temperature of the product should not exceed 40°C.
- Product battery should not be placed in an overheated environment (over 60°C).
- To prevent potential electrical damage ,please be recommended to use the power adapter and the USB cable provided with the packing only.