

FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



RHINO INSTRUCTION MANUAL

FCC STATEMENT: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 -Reorient or relocate the receiving antenna.
 -Increase the separation between the equipment and receiver.
 -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 -Consult the dealer or an experienced radio/TV technician for help.1

Thank you for choosing our remote control toys.

To ensure proper use, please read the instructions below and check the products before use have enough understanding.

Electronic control products:It is suitable for children over 6 years old to use, and all electronic products should pay attention and prevent clicks when using.

Maintenance:


This product contains electronic components, do not enter the water or use in a humid environment, please wipe the surface dirt with a rag.

1. Set the switch on the seat of the car and the remote control "OFF". (If there is a switch)

2. Open the battery cover using a crosshead screwdriver.

3. Install the rechargeable battery string according to the following figure, and install the batteries according to the + and - poles in the battery box.

4. Close the battery box and secure it with the crosshead screws.



Remote control and car operation


1. Turn the switch ON the car and remote control to "ON" Location. (If there is a switch)

2. Then operate the car.

3. When your car starts to lose performance, power, or When functional, it may be time to change the battery or charge. The battery is charged.

Note:

When the remote control can't control the remote control car. First remove the remote control battery and re install it. Battery, and then turn off the remote control car power. Turn on the power, and then operate the control. The frequency of the receiver is realigned.



The remote control car uses a 7.4V lithium battery
 If it is a AA battery base, please use 6 AA battery
 (to be purchased separately)

Remote control function description



The remote control uses two 1.5V "AA" batteries (to be purchased separately)



RHINO INSTRUCTION MANUAL


Forward /backward

Operate the "Forward/backward" button to remote control the car forward and backward




Left 360°rotation/Right 360°rotation

Operate the left/right buttons to rotate the remote control car 60° left and right. Rotate 360°. Operation Forward + Left button to turn left, operation Forward + Right button to turn right



Left / right drift

Operate "swing arm" button, remote control car swing arms



TURN/RIGHT LEFT

Press the back button to make the car stand (If unable to stand, please wipe the rear tire with a dry cloth)




Quick swing arm

Quick switch between left and right buttons, quick arm swing of Radio-controlled car



One click demonstration

Operate the "one-button demonstration" button, and the remote control car has its own stunts Demonstration



Quick swing arm

Operate the 'Sound Effect' button to emit a simulated sound effect