

OM-BT01



# WIRELESS BLUETOOTH SKI HEADPHONES

USER MANUAL

# THANKS FOR CHOOSING OUTDOORMASTER WIRELESS BLUETOOTH SKI HEADPHONES OM-BT01.

The OM BT01 is a wireless headset designed to provide over 10 hours of audio emission, flexibility with syncing of personal devices, as well as fitment compatibility with the vast majority of ski helmets on the market. Thoroughly designed to make trips on the mountain feel closer at home without feeling disconnected from the world. Our in-house developed micro-chips are enclosed in a custom fabricated wireless headphones that fit snugly inside your protective helmet. The expected power life for the battery is roughly 10 hours, based on conditions as well as operations selected. This allows you to get to jamming without missing anytime from the power to answer missed calls, and even adjust music playlists. The built-in microphone allows you to answer calls so you can lock schedule and without having to delay the session. Get connected with your friends, don't let your activities get in the way.


<b>PACKING LIST</b>	<b>01</b>
<b>USER INSTRUCTION</b>	<b>02-05</b>
<b>HEADPHONE PARAMETERS</b>	<b>06</b>
<b>DECLARATION</b>	<b>07-12</b>

# PACKING LIST

01



Headphone \*1



USB-C Cable \*1



USER MANUAL \*1

# USER INSTRUCTION

02

- ① Press and hold the right button  for 5 seconds until you hear "Power on", the headphone will enter Bluetooth pairing mode for the first used and the indicator light flashes.
- ② Select "OM BT01" on your mobile phone or other device you want to use for pairing.
- ③ When pairing is successful, the indicator blinks slowly and you will hear "Pairing", to commence enjoying the harmonizing audio experience by "OutdoorMaster"!

Please see more details below  
for more Instructions:



# BUTTONS

# FUNCTIONS



Pairing

Play/Pause

Answer Incoming Call

Activate Voice Assistant

Hang Up Incoming Call  
/ Hang Up Ongoing Call or Voice Assistant

Power Off

Volume Up

Previous Song

Volume Down

Next Song

Re-pairing a New Device

## PLAY CONTROL

## VOICE INDICATIONS

04

Pressing and holding it for 5 secs	Power on
Click	/
Click	/
Double-click	/
Double-click	/
Pressing and holding it for 5 secs	Power off
Pressing and holding it for 3 secs	Single "Beep"
Click	/
Pressing and holding it for 3 secs	Single "Beep"
Click	/
Pressing Both and holding it for 5 secs	Bluetooth disconnected

1. When the headphones are successfully paired with Bluetooth, the white light every 3 minutes.
2. Unpaired headphones will automatically shut down within 5 minutes.
3. When the headphones' battery is low, the red light steadies on, and the voice prompts "Low battery" every 3 minutes for twice and then the headphones automatically shut down.
4. When charging, the headphones can not be used, the red light steadies on, then the white light constant after a full charge.

# HEADPHONE PARAMETERS

06

Bluetooth Version	V 5.3
Reception Distance	Around 32 feet (unobstructed)
Hole Size	40mm
Hole Impedance	32 ohms +/- 15%
Battery Voltage	3.7 V
Battery Capacity	300mAh
Input Voltage	5V
Input Current	1A
Charging Time	About 2 hours (Indoor temperature)
Playback Duration	About 15 hours (Full charge, indoor temperature, 60% volume)
Usage Temperature	-4°F to 113°F (-20°C to 45°C)
Charging Temperature	32°F to 113°F (0°C to 45°C)

# DECLARATION

*Please read and keep all safety and use instructions.*

07

**WARNING:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not

occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **IMPORTANT SAFETY INSTRUCTIONS**

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.

7. Only use attachments/accessories specified by the manufacturer.
8. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## **WARNINGS/CAUTIONS**

- Do NOT use the headphones at a high volume for any extended period.
- To avoid hearing damage, use your headphones at a comfortable, moderate volume level.
- Turn the volume down on your device before placing the headphones in/on your ears, then turn the volume up gradually until you reach a comfortable listening level.
- Do NOT use your headphones while driving for phone calls or any other purpose.
- Do NOT use the headphones if they emit any loud unusual noise. If this happens,

turn the headphones off and contact OutdoorMaster customer service.

- Remove headphones immediately if you experience a warming sensation 10 loss of audio.
- Do NOT use the headphones as aviation communication headsets.
- Contains small parts which may be a choking hazard. Not suitable for children under age 3.
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.
- To reduce the risk of fire or electrical shock, do NOT expose this product to rain, liquids or moisture.
- Do NOT expose this product to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the product.
- Do NOT make unauthorized alterations to this product.
- Use this product only with an agency-approved power supply which meets local regulatory requirements (e.g., UL, CSA, VDE, CCC).
- Do NOT expose products containing batteries to excessive heat (e.g., from storage in direct sunlight, fire or the like).
- Do NOT wear the headphones while charging.
- The headphones do not play audio while charging.

Bern Smith  
Giro Bolle  
OutdoorMaster  
K2 Pro-Tec  
Anon Sweet Protection

This product is suitable for most types of ski helmets on the market. It is designed to be used in earmuffs. Product damage caused by collision, water ingress or other improper use is not covered by our warranty. It is covered by a limited warranty from OutdoorMaster. For other warranty detail, please contact OutdoorMaster customer service or visit.

<https://outdoormaster.com>

**Model** - OM-BT01

**Manufacturer** - Qingdao Mingce Zhida Import and Export Trading Co.,LTD

**Address** - Room 1103, Building 1, No. 117, Yingshanhong Road, Huangdao District, Qingdao City, Shandong Province, China

**Tel** - 0755-84650856

**Official Website** - [www.outdoormaster.com](http://www.outdoormaster.com)

**Email** - [care@outdoormaster.com](mailto:care@outdoormaster.com)



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FCC Radiation Exposure statement

The device has been evaluatec to meeel general RF exposure requirement. The device can be used in portable exposure condition without restriction.



OUTDOOR MASTER