

Wireless Charger Bluetooth Speaker Alarm Clock

Product Parameters


Product Name	Wireless Charger Bluetooth Speaker Alarm Clock	Product Model	JY-03
Input Voltage	9V and 2.2A	Bluetooth Name	JY-03 Speaker
Power Output	10W	Product Size	127*112*55 mm

Packing List

1 x Cordless, Fastest, Type-C Charging Cable, User Manual.

User Guide

Bluetooth Connection And Auto Sync of Phone Time


Step 1: Please turn on the Power Switch. Then, long press  key to turn on Bluetooth.

Step 2: Please turn on your phone Bluetooth and locate the "JY-03 speaker" device to connect.

The clock will automatically synchronize.

Step 3: First Bluetooth pairing requires permission to access information.

Bluetooth Speaker Use

Please turn on the Power Switch. Long press  key to turn on Bluetooth.

The product beeps one time. The indicator light turns blue and flashes once.

Turn on your phone Bluetooth. Locate the "JY-03 speaker" device to connect.

If the connection is successful, the indicator light turns green and flashes once.

The product beeps one time.


USB Drive Playback Speaker Use

This speaker supports music format: MP3/WMA/WAV/FLAC/APE/RAAM.

Insert the USB flash drive into the slot and automatically play the audio file in order after recognition.


Tip: If the USB drive does not support charging and output power supply.

Speaker Key Use

1. Bluetooth / Play/Pause Key 


Long press this button to turn on/off Bluetooth.

During music playback, short press this button to pause/play.

2. Volume Down/Previous Song 


During music playback, short press this button to lower the volume.

Long press this button to switch to the previous song.

3. Volume Up/Next Song 

During music playback, short press this button to increase the volume.

Long press this button to switch to the next song.


4. Atmosphere Lamp 


Short press this button to turn on light.

Short press this button to adjust light colors.

Long press this button to turn off the night light.

The light colors include RGB, colorful RGB, white, orange, yellow, purple, blue, light blue, green, red.

5. Unpair Bluetooth 


Long press the  key for 2 seconds to cancel Bluetooth pairing.

White Noise/Meditations/Nature Sounds Use


Turn the power switch to "ON". The product is working normally.

Turn the power switch to "OFF". The product will be shut down.


Press the white noise function, please ensure that Bluetooth and USB speaker is turned off.

1. White Noise Play/Stop Key 

Short press this button to play/stop sound.

2. Volume Down/Previous Sound 

Long press this button to switch to the previous sound.

3. Volume Up/Next Sound 

During sound playback, short press this button to increase the volume.

Long press this button to switch to the next sound.


4. Tips


There are 12 songs, including 1 to 12 cycle selection respectively.

1 rain, 2 hand drum, 3 bird song, 4 cricket song, 5 bell, 6 wind, 7 stream, 8 waterfall, 9 ocean waves, 10 falling, 11 frog music, 12 meditation music.


The sound can play for 45 minutes, after reaching the 45 minutes, the sound is turned off.



Alarm Clock Use



1. Power ON/OFF Switch 

Long press the  key for 2 seconds to cancel Bluetooth pairing.


White Noise / Light Setting" button is not pressed, the alarm will turn off for the day after 10 minutes.



2. Alarm Clock 1 Switch 



Long press "Alarm 1 Set" key for 1.5 seconds to enter the time setting and the "Volume" is flashing, then press  or  key to select.

Then short press "Alarm 1 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Times Setting" key or wait for 5 seconds to confirm the ringtone and return to time display.



3. Alarm Clock 2 Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 1 Set" key or wait for 5 seconds to confirm the alarm and return to time display.



4. Snooze / Light Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.


6. Snooze / Light Setting 

Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.


Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.



Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.



7. Power ON/OFF Switch 

Long press the  key for 2 seconds to cancel Bluetooth pairing.


White Noise / Light Setting" button is not pressed, the alarm will turn off for the day after 10 minutes.



2. Alarm Clock 1 Switch 



Long press "Alarm 1 Set" key for 1.5 seconds to enter the time setting and the "Volume" is flashing, then press  or  key to select.

Then short press "Alarm 1 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Times Setting" key or wait for 5 seconds to confirm the ringtone and return to time display.



3. Alarm Clock 2 Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 1 Set" key or wait for 5 seconds to confirm the alarm and return to time display.



4. Snooze / Light Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.



8. Snooze / Light Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.



9. Snooze / Light Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.



10. Alarm Clock 2 Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.



11. Power off time memory protect function 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the time setting and the "Volume" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Times Setting" key or wait for 5 seconds to confirm the ringtone and return to time display.



3. Alarm Clock 2 Setting 



Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.


Lastly, short press "Alarm 1 Set" key or wait for 5 seconds to confirm the alarm and return to time display.

4. Snooze / Light Setting 


Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.



Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.



Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.

12. Voice Control 

When the product is not plugged in the power, the display screen automatically shuts down. When there is a sound greater than 90 decibels, the display screen shows for 6 seconds.

13. Wireless Charging Function 

Long press "Alarm 2 Set" key for 1.5 seconds to enter the alarm clock 2 setting and the "Hour" is flashing, then press  or  key to select.

Then short press "Alarm 2 Set" key to enter the "Rescue" flashing, press  or  key to select.

Lastly, short press "Alarm 2 Set" key or wait for 5 seconds to confirm the alarm and return to time display.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received from other authorized devices.

Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not properly installed and used, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to you or a nearby receiver, which can be determined by turning the equipment off and on, we advise you to take the following steps: (1) Reorient the equipment. (2) Increase the distance between the equipment and the receiver. (3) Consult the equipment user's manual for more information.

Note: This device is not responsible for any damage or modification not expressly approved by the party responsible for compliance. Such modifications could void the user's warranty for specific equipment.

The device has been evaluated to meet general RF exposure requirements.

The reported specific absorption rate (SAR) for wireless phones used for the purpose of communication is 1.6 W/kg (head) and 1.4 W/kg (body).

The device has been evaluated to meet general RF exposure requirements.

The maximum SAR for wireless phones used for the purpose of communication is 1.6 W/kg (head) and 1.4 W/kg (body).

The device must be at least 10 cm from the body when used for the purpose of communication.

The device must be at least 10 cm from the body when used for the purpose of communication.

Please read carefully before use

MADE IN CHINA

1

2

3

4

5

6

7

8

9

10

11

12