

# Product manual

Please read the instructions carefully before using and well keep it for future reference.


## 1. Warning:

- This product is suitable for children with age 4 and above.
- The car battery can not be replaced, but it is rechargeable.
- The remote control is replaceable button battery. The battery can only be replaced under the accompaniment of the adult as there is CHOKING HAZARD!
- Adult supervision is required during the charging process to avoid accident. Please press the charging plug. When it is not used for a long time. Please turn car switch to "off" and charged and maintained every 2 weeks.
- This product should avoid contact with water and chemicals to prevent damage.

## 2. Cautions:

- The main body of this product contains 1x3.7V rechargeable (the battery is not replaceable) and the remote control contains 1xCR2032 button battery.
- The removal and loading of batteries should be operated as per the polarity and voltage marks in the battery compartment.
- Non-rechargeable batteries can not be charged.
- Rechargeable batteries are to be charged under the supervision of the adult.
- Different types of batteries or old and new batteries cannot be mixed.
- Only batteries that are the same or equivalent to the recommended battery can be used.
- The exhausted battery should be removed from the remote control. If it is not used for a long time, please remove the battery from the remote control.
- The power ends are NOT to be short-circuited.
- Regularly check whether the wires, plugs, shell and other components are damaged or not. If any damage is found, please stop using them until they are well repaired. only USB cable recommended can be used in this model.


## 3. Function description of the remote control:



- A key forward, B key backward, C key left turn, D key right turn, E key switch, F key throttle output 100%, G key throttle output 30%, H key rise, I key decline.

- The brightness of the indicator of the transmitter has decreased and the controlling distance has become closer. Please replace the battery CR2032 in the transmitter. Press the door latch of the battery cover with a tool, open the battery compartment and replace with the battery of the same model as per the same direction and then close the battery cover.
- Please turn the remote off when you're not using it.

## 4. Function Description of this Model :



- When there is insufficient power, the car speed will slow down and the power will be switched off (please charge it in time when entering the mode of insufficient power)
- When there is no operation within 5 minutes, it will enter into Sleep Mode and need to press the power switch again to restart.
- The green light is "ON" during the charging process of the car and it will turn off when the charging is completed. The charging process needs to be supervised by an adult throughout the entire process. After the power is fully charged, the charging plug should be unplugged to prevent accident.
- The charging port is Type-C, which can be used as a universal charging head for all kinds of mobile phones, but it does not support quick charging.

## 5. Product parameters:

Alloy model 2.4G remote control, 2-gear speed regulation, 3.7V-200mAh rechargeable lithium battery

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.