


AMAYA



AEB-H360D
ANC USER MANUAL

Specifications:

- 1.Working voltage: DC 3.7V
- 2.Charging power: DC 5V/500mA
- 3.Speaker frequency:20HZ-20kHz
- 4.Charging time: About 2 hrs
- 5.Playtime: 25 hrs
- 6.BT version: 5.3+EDR
- 7.Support format: MP3/WAV
- 8.Mic sensitivity: -32 ±3 dB
- 9.ANC depth rate: 28db±2
- 10.Working range: 10-15 Ms
- 11.Product name : AMAYA Bluetooth wireless headset



Please read the manual fully before using this device.
Keep the manual for your further reference.

1

Operation:

For the first-time use, please ensure the headphone battery is fully charged. Insert the Type-C cable into the charging port and connect it to a power source for charging. During charging, the indicator light will turn on. The charging process is complete when the indicator light goes off. Charging takes about 2-3 hours.

When the headphone battery is about to run out, a warning sound will be emitted. Please charge the battery immediately.

Power ON/OFF:

Power On: Press and hold the multi-function button for 3 seconds, and the indicator light will flash red and blue. It is now ready for wireless connection.

Power Off: Press and hold the multi-function button for 5 seconds, and the indicator light will turn off.

Bluetooth Usage Guide:

The wireless mode provides hands-free calling and wireless music playback functions.

Turn on the headphones, and the indicator light will alternate between blue and red flashing. Then, enable

2

the wireless function on your phone and search for the device 'AMAYA-H360D'. Select it to establish a connection.

Once connected successfully, you can freely play music and answer/make calls.

Wireless Mode:

1.When the headphones are connected to your phone, for incoming calls, quickly press the call button once to answer the call, and press the button again to end the call.

2.Making a Call:
When the headphones are connected to your phone, double-click the call button to dial the last dialed or answered phone number. Press the button briefly to stop redialing. Press and hold for 2 seconds to end the call.

3.Rejecting a Call:
Press and hold the call button for 2 seconds, then release the button to reject the incoming call.

4.Music Control:
Press the (+) or (-) button briefly to adjust the volume. Press and hold the (+) or (-) button to switch to the track you want to play. Press the play/pause button briefly to play or pause the music.

3

ANC Mode:

1.Wearing the headphones correctly.

2.Press the ANC button to activate Transparent Mode or ANC function, and the indicator light will turn green.

Wired Headphone Function:

To use the wired headphone function, insert the 3.5mm plug into the "Line in" port, and connect the other end to a computer or another music device. The headphones can then be used as wired headphones.

In this mode, you can control the volume and tracks through the connected device.

4

FCC Warning Statement :

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

5