



Solar Crank Radio with Flashlight & Reading Lamp

YX-328

FUNCTION:

- | | |
|---------------------------------|------------------------------------|
| 1. Torch | 2. Flashlight Switch |
| 3. Tuner | 4. Volume |
| 5. FM /AM/WB (NOAA) | 6. SOS |
| 7. Reading Lamp Switch | 8. Solar panel |
| 9. Speaker | 10. Antenna |
| 11. Reading lamp adjusting axle | 12. Reading Lamp |
| 13. Frequency scale indication | 14. Tuning indicator |
| 15. Charging indicator | 16. DC 5V in/out/Earphone jack |
| 17. Hand Crank | 18. Solar panel charging indicator |
| 19. COB | 20. Battery indicator |
| 21. Battery Cover | |



RADIO OPERATION:

1. Turn the 'Volume' Dial clockwise to power on the radio and adjust volume.
2. Select FM/AM/WB with radio band, extend the antenna to get better signal reception.
3. Turn Tuner Dial to select station. Green tune indicator turns on when the station selected is fully

USE THE FLASHLIGHT

1. Press the flashlight switch to turn it on/off;
2. Press the first time to turn on the torch;
3. Press the second time to turn on the upper and lower COB;
4. Press the third time to turn on both the flashlight and the upper and lower COB simultaneously;
5. Press the fourth time to turn off all lighting.

USE THE READING LAMP

1. Lift up the solar panel, press the reading lamp switch to turn it on/off.
2. The reading lamp can be rotated 180 ° and can stop at any angle within this range.
3. Pull the reading lamp adjusting axle to adjust the reading lamp height

POWER SUPPLYING:

A. Hand-Cranking

- Turn the Hand Crank continuously in clockwise or counterclockwise at speed of 130-140 RPM to generate power.

B. Solar Power

- Expose the radio solar panel in direct sunlight.
- Solar panel will charge the entire device, including the radio, flashlight and SOS alarm.
- It is mostly used for maintaining the battery, to extend its life.

C. USB Port Charging

- Recharge it via supplied USB cable.
- Connect USB power (such as AC/DC adapter or computer USB power port) and the Micro USB jack of the radio with the supplied USB charging cable

SPECIFICATION:

- 4000mAh 3.7V Li-ion (capacity optional)
- USB DC 5V output TYPE-C USB DC 5V input.
- When the battery runs out of power, turn the hand crank for 2 minutes (130-140 revolutions per minute), the flashlight or reading lamp can continuously illuminate for 15-20 minutes, and the radio can work independently for 15-20 minutes.
- Unit weight: 506G
- Product size: 166.5x57x87mm

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.