
# Magnetic Wireless Power Bank

(L-WP-10L6)

## User Manual

### Product Introduction

Thank you for choosing our Magnetic wireless Power Bank Please read over carefully and keep this manual for your records



## Charging the device

1. Connecting the USB-C interface of the Magnetic wireless Power Bank to the power adapter


> 2.The Battery indicator glow white in charging mode A For a better charging experience, please use a power WOS evode above 20W

For a more accurate display of the power level, it is recommended to perform two charge/discharge cycles.



## Wireless Charging the phone

put the device on the middle of the phone back, it can be adsorbed automatically and charging the phone at the same time When using wireless charging, the wireless charging indicator is always on; after disconnecting from the phone, the wireless charging indicator flashes slowly for 10 seconds and then turns off; when the wireless charging area touches a metal foreign



## Wired Charging the phone

(USB-C Output

Use the charging cable to connect the magnetic wireless power bank and your phone

The magnetic function is only used to adjust the charging position



## Standard accessories









## Wireless applicable device

FCC

Devices built-in wireless charging receiver and support fast wireless charging

(Galaxy S9 Plus/S10/S10 Plus/Note 10/Note 10 Plus, Huawei P30 Pro/Mate30/Mate30 Pro/P40 Pro stand charger for Iphone XS Max/Xr/11/11 Pro/11 Pro Max and all Qi-enabled

Johone 12/13/14/15 series and above models

L-WP-10L6

10000mAh/3.85V/38.5Wh 6000mAh(5V=2A)

5V=3A.9V=2.22A 5V=2A,9V=2.22A

15W Max

Transmission distance:

102×70×14.3mm

≈188C (NW)

FCC ID: 2BG9U-B5L6

F©RoHS 🕅 (se Made in China

### IC: 29971-B5L6 FCC Radiation Exposure Statement The device has been evaluated to meet general RF exposure

requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

used in accordance with the instructions, may cause harmful

try to correct the interference by one or more of the following

Increase the separation between the equipment and

Connect the equipment into an outlet on a circuit different

Reorient or relocate the receiving antenna.

from that to which the receiver is connected.

interference to radio communications. However, there is no

(1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.

FCC Warning Statement ISED Canada Statement: Changes or modifications not expressly approved by the party

This device contains licence-exempt transmitter(s)/receiver(s) responsible for compliance could void the user's authority to that comply with Innovation. Science and Economic Development operate the equipment. This equipment has been tested and Canada's licence-exempt RSS(s). Operation is subject to the found to comply with the limits for a Class B digital device, following two conditions: pursuant to Part 15 of the FCC Rules. These limits are designed (1) This device may not cause interference. to provide reasonable protection against harmful interference in (2) This device must accept any interference, including a residential installation. This equipment generates uses and interference that may cause undesired operation of the device. can radiate radio frequency energy and, if not installed and

guarantee that interference will not occur in a particular The device has been evaluated to meet general RF exposure installation. If this equipment does cause harmful interference requirement. The device can be used in portable exposure to radio or television reception, which can be determined by condition without restriction. turning the equipment off and on, the user is encouraged to

IC Radiation Exposure Statement

Déclaration d'ISED Canada:

## Cet appareil contient des émetteurs/récepteurs exemptés de

licence qui sont conformes aux RSS exemptés de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

(1) ce dispositif ne peut pas causer d'interférence.

Consult the dealer or an experienced radio/TV technician (2) ce dispositif doit accepter toute interférence, y compris l'interférence qui peut causer un fonctionnement indésirable du dispositif.

Déclaration d'exposition aux radiations IC

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé sans restriction dans des conditions d'exposition portables.

CAUTION: Risk of Fire and Burns.

Do Not Open, Crush, Heat Above(25°C) or Incinerate. Follow Manufacturer's Instructions.

Ne pas ouvrir, écraser, chauffer au-dessus (25°C) ou incinérer. Suivez les Instructions du fabricant.

WARNING – When using this product, basic precautions should always be followed, including the following:

 a) Read all the instructions before using the product. Attention: risque d'incendie et de brûlures.

when the product is used near children.

c) Do not put fingers or hands into the product.

PERSONS IMPORTANT SAFETY INSTRUCTIONS

d) Do not expose power bank to rain or snow.

e) Use of a power supply or charger not recommended or sold by power pack manufacturer may result in a risk of fire or injury

f) Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or

INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO

b) To reduce the risk of injury, close supervision is necessary

injury to persons. g) Do not use the power bank that is damaged or modified.

Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury. h) Do not disassemble the power bank. Take it to a qualified

service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.

i) Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 100°C may cause explosion. The temperature of 100°C can be replaced by the temperature of 212°F.

j) Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.

k) Switch off the power bank when not in use.

SAVE THESE INSTRUCTIONS