# LC-02Bluetooth Speaker Manual Manual

Before using this product, please read this manual carefully for correct instructions to operate this product. Please keep this manual for reference.

## 1. Warm reminder

The company is constantly striving to improve product quality and functionality. Product design is subject to update without notice
This manual has been carefully checked and strived to be accurate. If there are any errors, the company will not bear the consequences.
The physical specifications shall prevail at the time of purchase. The schematic diagram is for reference only. The company reserves the right to interpret the contents of this information.
Non-professionals should not disassemble the machine by themselves to avoid unnecessary damage to the machine. When replacing the battery, only use the same type or equivalent type of battery to replace it. Please note that the positive and negative poles of the battery should not be left overheated or In a humid environment
When not using the machine for a long time, please charge the machine once a month to ensure that the battery is sufficient and the machine can be used normally when needed.

## 2. Button and function description



### 3. Product parameters

Product model: LC-02 Bluetooth version: 5.2EDR Charging voltage: 3.7V Output power: 5W Battery capacity: 500mAh

Standby time: 300H Product size: 93\*45.3\*155mm Product weight: 215g Freguency response: 150HZ-15KHZ Signal to noise ratio: ≥ 75db

#### 4. Solutions to conventional problems

- Unsuccessful connection and pairing
   t. Check whether the speaker is in the search state, or reboot
   Z. Too many peripheral Bluetooth devices make searching difficult, turn off other Bluetooth devices
   3. Check if there is any Bluetooth device connected to this machine around, it needs to be disconnected
- Low or distorted sound
- Please charge the battery when the voltage is low
   Check the volume of the Bluetooth device and adjust the volume to a suitable sound level different songs have different decoding rates and different response sound effects)

  3. Reopen the Bluetooth speaker and mobile phone digital device Bluetooth connection

Music breaks
 Whether it exceeds the effective connection distance of the speaker, or whether there is an obstacle between the speaker and the Bluetooth device

About charging

Charging adopts 5V 1A charging head, Micro USB Android cable, the red light inside the USB is on to indicate that the power is on, the first charging is 8H, and the next 4-6 hours each time

### FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.