

T9601 Wireless Microphone Manual



Function Description:

1. Push up the power button for startup/push down the power button for shutdown
 - a. Power on, no connection pairing status displayed, green light flashing slowly
 - b. There is a connection pairing status when turned on, and the green light is constantly on
2. Weak current indication (when the battery is under voltage, the red light flashes slowly)

Precautions

1. To achieve the best singing effect, the mouth and microphone should be kept at an appropriate distance. If they are too far away, it will affect the bass effect, and if they are too close, there will be airflow impact; To reduce airflow impact, the optimal angle between the microphone and the mouth is 45 degrees.
2. If the microphone is not used for a long time, please remove the battery to prevent battery leakage and damage to the microphone components
3. When temporarily stopping use, please turn the microphone switch to the "OFF" position to delay the battery life.
4. After prolonged use of the microphone, the low battery indicator light will turn on. To avoid affecting the performance, the battery should be replaced in a timely manner.
5. Please use two No. 5 dry batteries

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.