

User's Manual



Dear User

Thank you very much for choosing our product! Your laptop has powerful information processing capabilities and is also portable. Whether you are in the office, at home, or traveling, it is an efficient assistant that accompanies you all the time.

When you receive the laptop, please open the outer packaging box and carefully take out the contents. If there is any omission or damage, please contact the laptop supplier immediately.

The following text will help you master the methods and techniques for using this product.

Front



1. Face recognition high-definition camera

Enables you to unlock, chat, and take photos with face recognition.

2. Camera-status light

Turns on when the camera is in use.


3. Microphone

Provides digital sound input for audio recording and voice calls.

4. IPS panel

Provides visual output to the user.

Top



1. Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

When the computer is turned on, press the power button to put the computer into sleep state; press and hold the power button for four seconds to force shut-down the computer.

2. Precision touchpad

Move your finger on the touchpad to move the mouse pointer. Tap to left-click and two fingers tap to right-click.

3. Touchpad left-click area

Press to right-click.

4. Touchpad right-click area

Press to left-click.

5. Backup microphone port

The backup microphone port on a laptop is an additional audio input jack that can be used as an alternative microphone connection.

6. Power-on indicator

The power-on indicator on a laptop is a small LED light that visually confirms whether the laptop is powered on or off.

7. Capitalization indicator

Referring to a light or icon on a keyboard that indicates whether the Caps Lock key is active or not.

8. Keyboard switch indicator

The keyboard switch indicator on a laptop is a visual notification that signals the active keyboard layout or input language.

Right



1. TF-card slot

Reads from and writes to the TF card. The TF card reader slot on the laptop facilitates data transfer, storage expansion, and media playback using MicroSD (TF) cards.

2. USB 3.2 port

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 480 Mbps.

3. USB 3.2 port

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 480 Mbps.

4. Global headset jack

Connect headphones or a headset (headphone and microphone combo).

Left



1. Security-cable slot (wedge-shaped)

Connect a security cable to prevent unauthorized movement of your computer

Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

2. DC Jack

The DC Jack on laptop is a power input port that allows the laptop to be connected to an external power source, typically an AC adapter, to charge the laptop's battery and provide electrical power for operation.

3. Type-C port

Connect to external storage devices. Provides data transfer speeds up to 5 Gbps.

4. HDMI 1.4 port

Connect to a TV, external display or another HDMI-in enabled device. Provides video and audio output.

5. USB 3.2 port

Connect devices such as external storage devices and printers.

Provides data transfer speeds up to 5 Gbps.

Bottom



1. Right speaker

Provides audio output.

2. Air vents

Air vents provide ventilation for your computer. Clogged air vents can cause overheating and can affect your computer's performance and potentially cause hardware issues. Keep the air vents clear of obstructions and clean them regularly to prevent build-up of dust and dirt.

3. Service Tag and regulatory labels

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information. The regulatory label contains regulatory information of your computer.

4. Left speaker

Provides audio output.

Safety Warning

To avoid hazards such as fire, electric shock, and personal injury while using this computer, basic safety precautions should be followed, including:

- Read these instructions carefully before using the computer.
- Before setting up, place the computer on a stable surface.
- Keep the computer away from high temperatures, humidity, and dust.
- Do not hit or drop the computer to avoid damage.
- Do not spill any liquid onto the computer to prevent damage or cause a fire.
- Do not insert any objects into the computer's ventilation holes or other open slots.
- Ensure the power cord is not placed in a position where people can trip over it or step on it.
- If you do not plan to use the computer for a long time, unplug it.
- Do not disassemble the computer yourself; for safety, please have it serviced by qualified professionals.

Precautions Before Use

1. This product is only suitable for use at altitudes below 2000 meters in non-tropical areas.
2. Avoid dropping the machine or subjecting it to other strong impacts.
3. Do not use in environments that are too cold, too hot, overly humid, or dusty for extended periods. Avoid exposing the machine to direct sunlight.
4. Try to avoid using it in environments with strong magnetic fields or static electricity.
5. If water or other liquids are spilled on the machine, turn it off immediately. Wipe and dry the machine before using it again.
6. Do not use any chemical cleaners or other liquids to wipe the machine to avoid corrosion and moisture damage. If cleaning is necessary, use a dry soft cloth or paper towel.
7. The company is not responsible for any loss or deletion of data inside the machine due to unauthorized software or hardware operations, repairs, or other accidental circumstances, nor for any other losses caused by these.
8. Always back up your important data to avoid loss.
9. Do not disassemble the machine yourself; doing so will void the warranty.
10. The product manual and related software are subject to updates without notice. If there is a discrepancy with the product manual, please refer to the actual product.
11. Using the wrong model of charger may pose an explosion risk; ensure to use the original charger.

Shortcut Key Usage Instructions

1. FN+ESC: Sleep button
2. FN+F1: Airplane mode
3. FN+F2: Mute speaker
4. FN+F3: Decrease volume
5. FN+F4: Increase volume
6. FN+F5: Decrease brightness
7. FN+F6: Increase brightness
8. FN+F7: LCD/HDMI display switch
9. FN+F8: Turn off or turn on LCD screen display
10. FN+F9: Customized, default quick launch for Internet
11. FN+F10: Screen capture
12. FN+F11: Scroll lock
13. FN+F12: Enable numeric keypad
14. FN+Delete: Embedded key
15. FN+Space: Turn on/off touchpad

Specifications

Screen Size: 15.6 inch

Processor: Intel Celeron N5095, Turbo Boost 2.9GHz

Memory: 16/32GB DDR4

Hard drive size: 512GB/1TB SSD

Operating system: Windows 11 Professional

Optical drive: None

Graphics: Intel UHD graphics

Ports:

1* TF-card slot

3* USB 3.2 ports

1* USB Type-C port

1* Microphone/Headset jack

1* Security-cable slot (wedge-shaped)

1* DC jack

1* HDMI port

Battery: lithium-ion

Camera: 720p HD camera

Wireless: Yes

Bluetooth: Yes

Color: Grey

Product Dimensions: 14.17 x 9.9 x 0.5 inches

Item Weight : 3.26 pounds

Simple Troubleshooting

Cannot Power On

1. Ensure the AC adapter is connected to the computer and the power cord is plugged into a functioning electrical outlet.
2. Verify the computer is powered on (press the power button again to confirm normal operation).
3. If the above steps are correctly followed and the computer still fails to turn on, please promptly contact the supplier for assistance.

When the Computer Screen Does Not Display After Turning On

1. Confirm that the HDMI and DP (DisplayPort) cables are connected properly.
2. Ensure that the display's input mode is set correctly.

A black screen appears while the computer is running

1. Examine the power indicator's status to verify if the device is in sleep mode. Attempt to wake it by pressing the power button.
2. Determine if the monitor has entered sleep mode.

The computer is Unresponsive

1. To perform a forced shutdown, press and hold the power button, then turn it back on.
2. Alternatively, disconnect the power cord and then reconnect it.

No sound from the speaker or headphones

1. Verify if the mute function is turned off.
2. Check if you have selected the speaker or headphones as the playback device.

Sincerely, if you experience any issues during use, please do not hesitate to contact us. Thank you for your support and we wish you a happy and fulfilling life!

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction
Specific Absorption Rate (SAR) information:

This product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: P10 (FCC ID: 2BGQN-P10) has also been tested against this SAR limit. The highest SAR values for body are 0.35 W/Kg. This device was tested for typical body-worn operations with the product kept 0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0cm separation distance between the user's body and the product. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. Body-worn Operation
This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0cm must be maintained between the user's body and the product, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components.

Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.