


LED RGB Digital Wall Clock





Please read this manual carefully
when using this product for the first time to get the best experience

Main Function


- 1、8-Digital LED Time Display
- 2、Night light
- 3、Automatic time synchronization
- 4、30 minute countdown
- 5、Double alarm clock and Super loudly ringtone
- 6、Three different display modes
- 7、Sound control screen display
- 8、Automatic daylight saving time

MEISHIDAofficial@outlook.com



Set up

1. Tear off the screen protector and remove the battery insert before use.
2. Connect the DC power plug to the back connector of the alarm clock, and the USB plug at the other end is connected to the charger to plug into the 100V-240V home socket.



MEISHIDAofficial@outlook.com

Time Setting

Method 1

When powered on for the first time, you need to set the time

1: Click **time set** to confirm to enter the clock setting clock bit will flash, press +- to set the current clock

2: Click **time set** to confirm to the minute to set the minute bit will flash, press +- to set the current clock

3: Click **time set** to confirm to the minute to set the minute bit will flash, press +- to set the current minute

4: click **time set** confirm to enter the year to set the year bit will flash, press+- to set the current year


5: click **time set** confirm to enter the date setting date bit will flash, press +- to set the current date.


Setup complete

Method 2

When powered on , the  logo bit will flash.

Turn on your phone's Bluetooth, connect to the **MshDigitalClock**, and the clock will automatically calibrate the time.





Time Setting (Remote Control Setting)

1. Click **TIME SET** to enter the time setting

In the time display state, click **TIME SET** to enter the time setting, the clock bit will flash, press **+** **-** to set the current clock.

2. Click **OK** to confirm

Click **TIME SET** to enter the minute setting, the minute bit will flash, press **+** **-** to set the current minute.

3. Click **OK** to confirm

Click **TIME SET** to enter the year setting, the year bit will flash, and press **+** **-** to set the current year.

4. Click **OK** to confirm

Click **TIME SET** to enter the date setting, the date bit will flash, press **+** **-** to set the current date, and the setting is complete.

5. Click **OK** and exit the time setting.

User prompt:

in the time setting state, do not operate for 10 seconds, automatically exit the current setting.

Alarm Setting

Enter the alarm 1 setting

- 1: Click **alarm1** button the clock to flash, click **+** - to set the alarm clock, click **alarm1** button again to confirm
- 2: Click **alarm1** button the minute setting, the click **+** - to set minute, click **alarm1** button again to confirm
- 3: Click **alarm1** enter the daily alarm(1-7), weekday alarm(1-5) and weekend alarm(6-7), click **alarm1** button again to confirm
- 4: Click **alarm1** button to select sound Size, the click **+** - to select, click **alarm1** button again to confirm

Alarm Setting (Remote Control Setting, Take alarm 1 as an Example)

1. Click  to enter the alarm 1 setting
Click , and the clock will flash, click   to set the alarm clock
2. Click  to confirm
Click  to confirm to enter the minute settings, and click   to set minutes
3. Click  to confirm
Click  to enter the daily alarm (MON-SUN), weekday alarm (MON-Fri), and weekend alarm (SAT-SUN), as shown in the following figure
4. Click  and exit the alarm setting

Alarm every day:	MON TUE WED THR FRI SAT SUN
Weekday alarm:	MON TUE WED THR FRI
Weekend alarm.	SAT SUN

Operation When the Alarm Goes Off

After the alarm is turned on, the alarm will be turned on at the preset time:

when it is time for the alarm, the alarm will start to go off and wake you up.

When the alarm goes off, you can do the following:

1. Stop this alarm

When the alarm goes off, click **remote control alarm button/ long press the snooze mode button** on the device to stop this alarm without affecting the next alarm.

2. Snooze Mode

When the alarm clock rings, press **any button** on the device to enter a 5-minute snooze mode. After the snooze mode ends, the alarm clock will continue to ring.

3. When unmanned

When the alarm goes off **20MIN** without any operation, this alarm will be stopped automatically, and the next alarm will not be affected.

Night Light Mode

1. Light switch

In the time display state, click  to turn on the night light.

2. After the night light is turned on, press  again to switch to different brightness levels, and then long press  to turn off the night light.

Another method

Press the physical button on the machine  to turn on the night light.



Screen Brightness Control



In the time display state, click to  adjust the screen brightness in turn (high/light-secondary-high light-mediumlight-low/light-off)

Countdown setting

1.Countdown switch



In the time display screen, click  to turn on the countdown, the countdown flashes, click   to set the countdown, set the duration (1~30MIN), and long press  to turn off the countdown.

User prompt:

- 1.The countdown is over and the bell rings for 10 seconds.
- 2.In the countdown setting state, there is no operation for 10 seconds, and automatically exits the current setting

Screen Font Color Setting




In the time display state, click  to toggle screen font colors(white, red, green, blue, gradient, magic color, left and right gradient, up and down gradient)

Color selection


When the display color changes, long press  to select the current color to keep it displayed.

Daylight Saving Time Setting



As shown in the figure on the left: in the time display state, click  to open or close daylight saving time.

12H/24H Setting




As shown in the figure on the left: in the time display state, click  to switch 12H/24H.

Automatic Photosensitive Setting




As shown on the left: in the time display state, click  to open or close automatical sense light.

Bluetooth Switch



As shown on the left: in the time display state, Press  to turn on Bluetooth, and the  on the screen will flash. Long press  to turn off Bluetooth, and the  on the screen will disappear.

Mode Switching



As shown on the left: in the time display state, Press  to switch between different modes of content display.

01 Mode: Display Time;

02 mode: Display date;

03 Mode: Alternating display of time, date and year.

Sound Switch



As shown in the figure : in the time display state, Press  and the screen will display 'ON', indicating that you have entered **Voice Control Mode**.

When there is no sound around for **5 minutes**, the screen will automatically turn off, and when there is sound, the screen will automatically turn on.

Pressing  will display 'OFF' on the screen, indicating that the voice control mode has been turned off.

The screen will remain on continuously

(The default for the first startup is to turn off the voice control mode)

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator & your body.

MEISHIDAofficial@outlook.com

Installation method



- 1.Align the positioning hole to nail the hanging nail to the wall.
- 2.Hang the alarm clock on the nail.
- 3.Installation completed.

CE FC RoHS  

MEISHIDAofficial@outlook.com