


Smile Station

Instruction Manual



Contact Email support@smilecharging.com

Package Contents





Cases Should Avoid




Metallic Design



Pocket Case



Uneven Surface



Thickness over
0.12 Inch (3 mm)



Silicon cases of AirPods and Watch may cause unstable charging.

Magnetic Ring Guideline


For Non-MagSafe Case: use magnetic ring for better charging experience.

For MagSafe Case: please kindly skip this page.



Key Steps

- 1 Identify Your Phone Model
- 2 Align Position as Shown
- 3 Stick the Magnetic Ring




Remove the backing sticker
before attaching it




Correct Usage



✓ Correct Placement



✗ Wrong Placement



Metal

Metallic objects will cause product malfunction.

✗ Foreign Objects



✗ Other Low Power Plug

✗ Other Chargers

Universal Compatibility

15W For Apple iPhone

iPhone 11 to 16 Series
iPhone 8 & X Series



3W For Apple AirPods

ONLY SUPPORT Apple Airpods 3rd Gen or AirPods Pro with MagSafe Charging Case

NOT SUPPORT Apple Airpods 1st/2nd/3rd Gen with Lightning Charging Case



2.5W For Apple Watch


Apple Watch SE & Ultra
Apple Watch 2 to 9





Safety and Get Help

1. Please use the Charger included and cable to charge.
2. DO NOT put metal or magnetic objects in the charging areas.
3. If the charging station causes overheating to your device,
please check Pages ② and ④ to confirm whether you use
the charging station properly.





Troubleshooting for Charging Issues

Phone Not Charging Consistently

1. Ensure your phone case is either a MagSafe case or a case with a magnetic ring attached.
2. Unplug the charging adapter and plug it back in after a few seconds.

AirPods Not Charging

1. AirPods 3rd gen or AirPods Pro with MagSafe cases are compatible.
2. 1st/2nd/3rd gen AirPods with Lightning cases are not compatible.
3. Check your AirPods package or order to make sure your AirPods support wireless charging.

Watch Not Charging

1. Unplug the charging adapter and plug it back in after a few seconds.
2. Update watch software through Watch app on the Phone > General > Software Update.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.