

# Quick Installation Guide

## Ceiling Mount Access Point




Scan for  
EAP Start Guide

Note: EAP787 is used as an example throughout the guide. Images may differ from your actual product.

©2025 TP-Link 7106512107 REV1.0.0

### Package Contents



1×



1×



2×



1×



4×



4×



4×



4×



4×



2×



2×




2×

Note: Accessories may vary by region.

### Installation


#### Option 1

Ceiling Mounting (on a Tile)




#### Option 2

Ceiling Mounting (on a T-bar)




#### Option 3

Wall Mounting




#### Option 4

Junction Box Mounting



#### Option 1



1×



4×




4×




4×


1




2




3




4



5



#### Option 2




1×




2×


1




2




3




4




5



6



Option 3




1×


4×

4×


1




2




3




4



5



Option 4




1×

2×

2×


2×

Choose the accessory screws that fit your junction box.  
Compatible wall junctions are as follows:




For simplicity, an 86 mm wall junction box is used as an example.


1



2




3




Power On

Option 1: Via PoE Switch




Option 2: Via Power Adapter



Configuration


Option 1: Standalone Mode

Configure and manage each EAP on its standalone page.



Option 2: Controller Mode

Configure and manage EAPs (and other Omada devices) centrally with an Omada Controller.



Omada App

With the TP-Link Omada app, you can access and manage your Omada devices at a local site or remotely with a tap of your phone.



More Configurations

For more configurations, refer to the User Guides of the Omada Controller and Omada Access Points at:  
<https://support.omadanetworks.com/document/>



Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed.
- The EAP can be powered only by a power adapter or a PSE device (such as a PoE switch) which complies with Power Source Class 2 (PS2) or Limited Power Source (LPS) defined in the standard of IEC 62368-1.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011 /65/EU, and (EU) 2015/863. The original EU Declaration of Conformity may be found at <https://www.tp-link.com/en/support/ce/>

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at <https://www.tp-link.com/support/ukca/>

More Resources

Main Site	<a href="https://www.omadanetworks.com">https://www.omadanetworks.com</a>
Video Center	<a href="https://support.omadanetworks.com/video">https://support.omadanetworks.com/video</a>
Documents	<a href="https://support.omadanetworks.com/document">https://support.omadanetworks.com/document</a>
Product Support	<a href="https://support.omadanetworks.com/product">https://support.omadanetworks.com/product</a>
Technical Support	<a href="https://support.omadanetworks.com/contact-support">https://support.omadanetworks.com/contact-support</a>

Warranty

For details on the warranty period, policy, and procedures, visit <https://support.omadanetworks.com/warranty-services>.

Support

For technical support, user guides, and other information, please visit <https://support.omadanetworks.com>, or simply scan the QR code.

