

# KSI-2400 User Manual

Model: KSI-2400

## User Operation

1. Prepare a Windows computer. Turn on the computer.
2. Plug KSI-2400 USB cable to the computer's USB port.
3. There is a radar sensor to detect the presence of user in front of the computer.
4. When the sensor detects the absence of the user, it will send out the screen lock signal to the host.
5. Then, after the user come back to the front of the computer, it will send out login signal to the host.
6. The radar sensor LED will be at the front side (LED on the right hand side, KSI logo on the left hand side).
7. The radar sensor LED display indication is:  
When a person is detected, the LED will show the zone's color (Yellow color for zone 1, Green color for zone 2, Cyan color for zone 3, Blue color for zone 4, Purple color for zone 5).
8. When it detects the person is away, the zone's color will start to flash.
9. After 5 seconds, when it confirms the person is left and the keyboard sends lock screen message to the computer, the LED will show red color.

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.