

N3473 remote control manual

1、Specifications:

YLH-C1075-3473

2、Product images



3、Electrical parameters

- 3.1 battery: CR2032 3V
- 3.2 Standby power consumption current: $\leq 1.0\mu A$
- 3.3 Maximum operating current: $8.0\sim 9.3mA$
- 3.4 Stabilize the remote control distance ≥ 10 meters (Test conditions: battery voltage 3.0V)

4、Functionality as well as operational requirements

4.1 Description of the key function:



Stretch the button, press the jog; Press and hold, and the push rod motor will continue to move



Fold the button, press and click; Press and hold, and the push rod motor will continue to move



Unlock button, you need to press the unlock button first, and the extension and folding functions can be activated (no button operation within 30S, you need to unlock again)



Empty key, not used



LED indicator, when there is a button to operate, the indicator light is on

4.2 Operational Function Requirements:

When using, press the unlock button first, and then press the other function keys

When the brightness of the indicator light is significantly dimmed or the remote control is not sensitive, please replace the CR2032 battery

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.