

Quick Start Sheet

1

Install the Light Stream Cloud™ APP



2


Bulbs are Color Coded for each Channel*



*Sold Separately. Compatible only with LS Gen 3 bulbs

3

Install the bulbs onto the wire in channel order



!

Test light the bulbs on the sockets before installing onto your roof-line. Make sure the bulbs are installed tightly into the sockets.

!

Bulb's wire must be plugged directly into the controller. Maximum 200 bulbs per Controller

4

Open the App and find the + sign to pair a controller.



5

Activate the controller for Wi-Fi Mode or Hotspot Mode.

Wi-Fi
(Recommended)

Hold button until
flashes blue.
(6 Seconds)



HotSpot
(If Wi-Fi is not
available)

Press button once.
(Flashes white)

6

LED Status Codes*:



Green Steady On: Wi-Fi Connected
Green Flash: Wi-Fi + Schedule
Red Flash: No Connection

Blue & White Steady On: Default Mode. Press button once for Hotspot mode, 6 Seconds for Wi-Fi Mode


White Flashing: Hotspot Pairing
Blue Flashing: Wi-Fi Pairing

*See on-line manual for more codes

LIGHT STREAM
CLOUD
PATENTED & PATENT PENDING

7

Choose Wi-Fi or Hotspot & Continue the setup process



8

Create a Theme



Choose up to three colors to fade per channel

Make a channel twinkle


Adjust fading speed

9

Set A Schedule

SIMPLE SCHEDULE

Repeat the same schedule every day




CUSTOM SCHEDULE

Create schedule "Blocks" to customize your light schedule

10

Select the button for On, Off or Timer Mode.



?

Need more info? Scan this QR Code

Learn More about:

- Troubleshooting
- Pairing 2 or more controllers Together
- Installation Tips
- Themes
- Schedules



WWW.VILLAGELIGHTING.COM

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body