


wireless speaker

USER GUIDE

25005




Long press: ON/OFF
Short Press: Play/pause

PAIRING MODE:

1. Long Press “⏻” turn on the “P10”, the BT light will blue flash and “gulu” to voice prompt comes out means in pairing mode
2. Activate audio device and search for the “P10”, select it to connect. “P10” will announce “gulu” and the indicator light turn solid blue, your device is successfully paired.

Remark: When you turn on “P10” if 10 mins not connect with device, it will into auto power off mode.

TWS MODE:



1. Turn on two speaker.
2. Short press “⏻” 2 times any one into tws mode.
3. Search “P10”, connect it.
4. Short press any one two times turn off TWS mode.

FAIL TO PAIR TROUBLESHOOTING

Make sure the device is in pairing mode and the wireless is working. Please reset (ON/OFF)the power switch again.

Check that the “P10” is in pairing mode.

Ensure your device is with in Wireless use range.

Reset your device to activate Wireless.

Ensure that your device is not connected/pairedto any other Wireless devices as Wireless can only be paired to one device at a time.

CHARGE MODE:

-Make sure the speaker is turn off.

-Plug the speaker to a powered USB-C port.

-While charging the LED indicator will be Red.

-Once fully charged, the LED indicator will be off.

⚠ WARNING

- Do not expose the “P10” to liquid, moisture or excessive humidity.
- Do not expose the “P10” to excessive heat or open fire.
- Do not drop the “P10”.
- Discharge and charge the “P10” at least once a month to guarantee the quality of the internal battery.

DISPOSAL

The “P10” contains an internal battery. Please dispose of this product according to the regulations in your country.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.