

Our company reserves the right to improve the product and manual without prior notice.
The appearance of the product shall be based on the actual product;



This book has been carefully checked, but it cannot be ruled out that there may be printing errors or misunderstandings in the content. We apologize for any inconvenience caused and reserve the right to interpret. Improper disposal of public waste can cause environmental pollution.

♻️ Improper disposal of waste can cause environmental pollution.

Massage chair

Operation instructions

Model : MC01



Reminder: This product is a personal health massage product and cannot replace drugs or medical devices!

Please read this manual carefully
before using the product and keep
it for future reference

Catalog

Precautions	01
Safety protection	01
Warm reminder	02
Maintenance	02
Technical parameters	03
Circuit schematic	03
Preparation before massage	04
Warning before use	05-06
Part name	07
Introduction to control panel functions	07
Instructions for use	08
一、Turn on the motor power	08
二、Massage function control operation	08
1) Shoulder position compensation	09
2) Menu bar interface	10
3) Home page-More programs	10-11
3) 12 mode function description	11
4) Home-Settings	12
5) Automatic	13
6) Manual	14
7) Air bag	15
8) Posture	16
9) shortcut manual operation instructions	17
10) End of massage	18
三、Cut off the power supply of the whole machine	18
Voice command	19
Common fault analysis and troubleshooting	20
Name and content of hazardous substances in products	20
After-sales service guarantee card	21

/After-sales service guarantee card

After-sales warranty contact card

(The following contents are required)

Purchase platform: Purchase account:

Transaction number: Warranty/return model:

Reasons for warranty/return or exchange:

Contact number: Convenient contact time:

Please be sure to contact customer service before sending the product back to ensure that the repair/return time can be effectively shortened!

/ Common fault analysis and troubleshooting

Fault phenomenon	Possible Causes	Approach
Sound (running sound) * Airbag inflation sound * The sound of air bag deflating * Electromagnetic network switching sound * Air pump working sound	The product makes a running sound when it is working.	This sound is normal and does not require treatment.
Overall it doesn't work at all	The power plug is not inserted into the socket The outlet switch is not turned on The massage button is not pressed	Check the power plug and socket, and make sure the plug and socket are in good contact and press the massage button
The massage suddenly stopped in progress	This product has just completed 20 minutes of rated working time and automatically switched to standby mode.	If you want to massage again, press the on/off button again. Turn on massage function
	If the rated use time is exceeded, the motor will be protected against overheating.	Shut down the machine, cut off the power supply, and wait for the motor to cool down be

/ Name and content of hazardous substances in products

Part name	Hazardous substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
Circuit board	X	○	○	○	○	○
leather	○	○	○	○	○	○
Wire	○	○	○	○	○	○
Motor	X	○	○	○	○	○
Sponge	○	○	○	○	○	○
Packaging materials	○	○	○	○	○	○
Metal rack	X	○	○	○	○	○
Plastic parts	X	○	○	○	○	○
This form is prepared in accordance with the provisions of SJ/T 11364. ○: Indicates that the content of the hazardous substance in all homogeneous materials of this part is below the limit requirements specified in GB/T 26572. X: indicates that the content of the hazardous substance in at least one of the homogeneous materials of this part exceeds the limit requirements specified in GB/T 26572. Note: The harmful substance content in the products disclosed in this table does not include batteries that need to be replaced regularly.						
 Under the normal use conditions described in this manual, the environmentally friendly use period of this product is 10 years. You can safe use it during the environmentally friendly use period.						

/ Precautions

In order to ensure safe and correct use of the massage chair, please be sure to read the operation manual in detail before using this product. In order to reduce the risk of fire, Risk of burns, electric shock, or injury to others, please follow these instructions:

- 1) Do not use power sources other than AC100-240V 50-60Hz.
- 2) When no one is using the machine, be sure to unplug the power plug of the massage chair from the socket. When not using the machine or before installing/disassembling parts, be sure to unplug the power plug from the socket in time.
- 3) To avoid fire, electric shock, or injury due to overheating, do not operate the product under other coverings such as pillows or blankets.
- 4) If the product is used by children or people with physical or mental disabilities or disabilities, adult guardian supervision is required.
- 5) Please be sure to use this product according to the purposes described in the user manual. Do not use spare parts not recommended by the manufacturer
- 6) Do not use this product when the following conditions occur: The power cord or power plug is damaged, the operation is abnormal, if it is dropped to the ground or otherwise damaged, or dropped into water, please return the product to the maintenance service center for inspection and repair.
- 7) Do not drag the power cord to move this product or use the power cord as a handle.
- 8) The power cord must be kept at a safe distance from the heating surface.
- 9) Do not operate this product when the air outlet is blocked. Please keep the air outlet unobstructed to avoid being blocked by lint, hair, etc.
- 10) Do not insert or drop objects into any opening of the product.
- 11) Please do not use this product outdoors.
- 12) Do not operate this product in places where spray products are used or in places full of oxygen.
- 13) To cut off the power supply, please turn off all operating controls and then unplug the power plug from the socket.
- 14) Do not cover the massage chair to avoid overheating, which may cause malfunction or fire.

/ Safety protection s

- Do not use the massage chair in excessively humid or dusty environments to avoid electric shock or mechanical failure.
- Do not use the massage chair when the room temperature exceeds 40°C.
- Do not place the massage chair near an electric heater, stove or in direct sunlight.
- The massage chair is designed for personal use and is not suitable for any commercial use.

⚠ Careful

- Message chairs are for indoor use only.
- Use the massage chair at a low room temperature and do not raise the temperature suddenly. It is recommended to gradually adjust the temperature to the normal range before use.
- If the massage chair is moved from a low-temperature storage location to a warm environment for use, water vapor may accumulate in the machine parts, which may affect the normal operation of the machine and even cause machine parts to malfunction. It is recommended that after moving, leave the product at normal room temperature for 1 hour before starting to use it.

/ Warm reminder

- The power switch must be turned on before other functions can be selected.
- Children should use this massage chair under adult supervision to avoid equipment damage and children's injuries due to improper operation.
- Please do not let children climb on this massage chair to avoid falling injuries.
- When using a massage chair, adjust the massage intensity of the chair. If the massage force is too small, it will not have the proper stimulating effect. If the massage force is too high, it will easily cause fatigue and damage the skin. The massage force and frequency should be increased from less to more, from light to heavy.
- When using a massage chair, you should relax your body and mind. During massage, in addition to concentrating your thoughts, you should especially be calm and do not tense up your whole body. Patients with heart disease, hypertension, osteoporosis, patients with localized skin damage, ulcers, bleeding, tuberculosis, and tumors, as well as people who are overly hungry, overfull, alcoholic, or overtired are not suitable to use the massage chair.
- To avoid reducing the massage effect or causing injury, do not use the massage chair with other therapeutic equipment such as electric blankets at the same time.
- Do not use the massage chair within 1 hour after eating to avoid adverse effects.
- Do not use the massage chair when your hands or other parts of the body are wet, and do not insert or unplug the power plug.
- Do not insert any objects or flammable items into the massage chair. This may cause electric shock, malfunction, or cause a fire.
- If you feel any discomfort during massage, please stop immediately.
- This product is not intended for self-diagnosis or treatment. If diagnosis or treatment is required, it should be handled by professional medical personnel.
- Please do not use this product if you are taking medications for medical conditions or if you are pregnant or during your menstrual period.
- When using the massage chair, you must master the massage time. Each massage should last for 15 minutes. Each person (time) should not use it for more than half an hour (when it reaches half an hour, the massage chair should rest for ten minutes before using it). If used continuously for a long period of time, the overheating protection device may be activated and the power will be automatically cut off.
- The surface of the appliance is hot, so people who are sensitive to heat must pay attention when using it.
- Do not directly massage elbow joints, knees, chest, abdomen, etc.

Situations when it is not appropriate to use a massage chair:
If the following situation occurs, please turn off the switch immediately, cut off the power supply, and contact our company.

- Accidentally spilling liquid on the massage chair may cause electric shock.
- The cloth cover of the massage chair is damaged and the internal parts are exposed.
- If abnormal or severe pain occurs during massage, please stop the massage immediately and seek medical consultation.
- If you detect any mechanical failure or abnormality during use, please stop using it immediately.
- If a current interruption occurs during use, care should be taken to avoid injury to the user due to sudden power restoration.
- When lightning occurs.

/ Maintenance

1. Please use neutral detergent and soft rag for daily cleaning. Do not use corrosive detergents.
2. If the power cord is damaged, it must be replaced by professionals of repair shop designated by the manufacturer. to avoid danger.
3. When this product is not in use or when cleaning, please unplug the power source to avoid danger.
4. Do not use any sharp objects to cut the surface of the product.
5. Do not place the product in a humid environment. It should be placed in a dry and ventilated place.
6. Do not press hard or put heavy pressure on the product.

/ Voice command

Voice control command			
NO	Command word		Reply content
	Function	Instructions	
1	Awakening word	Hello massage chair	Hello
2	Power on	Power on	OK, turn on the massage. I'm glad to serve you
3	Shut down	Shut down	OK, turn off the massage and look forward to serving you again
4	Easy massage	Easy massage	OK, it has been executed for you
5	Leisure mode	Leisure mode	OK, it has been executed for you
6	Pain relief	Pain relief	OK, it has been executed for you
7	Office mode	Office mode	OK, it has been executed for you
8	Sleep mode	Sleep mode	OK, it has been executed for you
9	Fatigue recovery	Fatigue recovery	OK, it has been executed for you
10	Shoulder Focus	Shoulder Focus	OK, it has been executed for you
11	Waist relief	Waist relief	OK, it has been executed for you
12	Lumbar Relaxation	Lumbar Relaxation	OK, it has been executed for you
13	Awaken vitality	Awaken vitality	OK, it has been executed for you
14	queen slim	queen slim	OK, it has been executed for you
15	exercise recovery	exercise recovery	OK, it has been executed for you
16	Heating	heating mode	OK, heating mode
17	Time	increase time	OK, increase time
18	Bluetooth	Turn on Bluetooth	OK, Turn on Bluetooth
19	Roller	Open the roller	OK, Open the roller
20	Automatic air pressure	Automatic air pressure	OK, Automatic air pressure
21	Shoulder pressure	shoulder pressure	OK, shoulder pressure
22	Hand pressure	hand pressure	OK, hand pressure
23	Leg pressure	leg pressure	OK, leg pressure
24	Back up	back up	OK, back up
25	Back down	back down	OK, back down
26	Zero gravity	Zero gravity	OK, Zero gravity

Attention: Please use standard English to avoid unrecognizable instructions. (Please follow our quotation to control it!)
If there is occasional failure to wake up, it is a normal phenomenon.
If it is not a massage chair malfunction, try waking up multiple times.


/ Instructions for use

10) End of massage


- During the massage process, press the shutdown button to turn off all massage functions and reset the backrest and legs.
- When the massage time is up, turn off all functions and do not reset the chair back and legs. If you need to reset, press the "standby" button to reset. If you need to reset, press the "standby" button to shut down and reset. During the reset process, press any button to emergency stop.



Turn off/on



三、Cut off the power supply of the entire machine and unplug the power cord.




Turn the power switch on the lower back of the device to the "0" (on) position



/ Technical parameters

Product Name	Massage Chair
Product model	MC01
Rated voltage	AC100-240V
Rated frequency	50/60Hz
Rated power	120W
Rated working time	20min
Safety Category	Class I


/ Circuit schematic



/ Preparation before massage


① Unboxing the massage chair

Integrated packaging, first open the box, then put down the legs to use.



② How to move the massage chair

When moving, use both hands to press down on the neck of the backrest until the small roller can roll, and then push it forward and backward.



Notice!


Do not move with people.

Do not use small pulleys on floors that are easily damaged.

/ Instructions for use

9) shortcut manual operation instructions

- On/off button : Press this button to turn on the massage function of the whole machine, and press this button again to turn off the massage function of the whole machine.
- Air bag strength adjustment key: In the air bag mode, press this button to adjust the air bag strength. Clockwise increases the air bag strength, counterclockwise decreases the air bag strength.
- Mode switching key : Press this key to cycle through 12 automatic modes.
- Set time key : Press this key to set the massage time in sequence. Setting time: 5-30 minutes.
- Manual mode : In automatic mode, press this button to select manual mode, 6 massage techniques: kneading, pounding, tapping, acupuncture, tapping, and massage.
- Manual intensity : In manual mode, press this button to adjust the manual massage intensity, ranging from 1 to 6. It is invalid in acupuncture mode.
- Bluetooth : Bluetooth is turned on by default when the massage chair is turned on. Press this key to turn off the Bluetooth function. Press this key again to turn on the Bluetooth function, accompanied by a prompt tone. Bluetooth hotspot name starts with: AMY-*****
- Heating : Press this key to turn on the heating function, and the icon will light up. Press this key again to turn off the heating function, and the icon will turn off.
- Foot roller : Press this button to turn on the foot roller function, the icon will light up, and the intensity can be adjusted in 3 levels. Press this button again to turn off the foot roller function, and the icon will turn off.
- Seat back raise : Press and hold this button to raise the seat back, adjust it to the best position and then release it to stop.
- Seat back lowering : Press and hold this button to adjust the seat back to the best position, then release and stop.
- Zero gravity : Press this button to turn on the zero gravity function, and the chair back will tilt to the maximum angle. Press again to turn off zero gravity, and the chair back will return to the power-on angle.
- Charging interface : The maximum output of the charging interface is DC5V/1A.



/ Instructions for use

8) Posture

Press "Menu Bar" to select "Sitting" and you will automatically enter the sitting interface. The sitting interface consists of chair back rising and chair back lowering, leg up, leg down, and zero gravity functions. The lower column of the interface is for heating parts, foot rollers, shutdown, and pause.


- Back up: Press and hold this button to raise the seat back. Adjust to the optimal angle and then release to stop. Fatigue recovery and comfortable sleep modes are ineffective
- Back down: Press and hold this button to lower the seat back. Adjust to the optimal angle and then release to stop. Fatigue recovery and comfortable sleep modes are ineffective
- Angle up: Press and hold this button to raise the legs. Adjust to the optimal angle and then release to stop.
- Angle down: Press and hold this button to lower the legs. Adjust to the optimal angle and then release to stop.
- Zero : Press this button, the chair back will fall to the.



/ Warning before use


⚠ Warning

Before using the massage chair, please remove hard objects from your pockets or jewelry you carry with you before massaging (such as keys, watches, etc.) to avoid damage to the product or personal injury during the massage process.



⚠ Warning


Do not unplug the power cord or directly turn off the power switch on the back of the massage chair during massage to avoid product damage or personal injury.



/ Warning before use


▲Warning

Do not remove or pull the power cord when in standby or powered on to avoid product damage or accidental electric shock; It is recommended to unplug the power cord and store it away when the massage chair is not in use.



▲Warning

When turning on the zero-gravity lying function, be sure to pay attention to whether there are children or pets staying or playing under the massage chair under the lower leg frame and backrest frame to avoid product damage and personal injury.



/ Instructions for use

7) Air bag

Press "Menu Bar" to select "air bag" and you will automatically enter the air bag interface. The air bag interface has air bag strength adjustment. It is composed of whole body airbag, shoulder airbag, arm airbag and leg airbag. The lower column of the interface is for heating parts, foot rollers, shutdown, and pause.

- Full body airbag: In automatic mode and manual mode, press this button to turn off the full body airbag function and turn it on again. Airbag massage, the icon corresponding to the massage part lights up, and the airbag massage is performed according to the steps set by the program.
- Shoulder airbag: Press this button to switch to shoulder airbag massage, the icon will light up, and perform shoulder airbag massage according to the steps set in the program.
- Arm airbag: Press this button to switch to arm airbag massage, the icon lights up, and perform arm airbag massage according to the steps set by the program.
- Leg airbag: Press this button to switch to leg airbag massage, the icon lights up, and perform leg airbag massage according to the steps set in the program.
- Air bag strength adjustment: In the air bag mode, click on the air bag strength level to adjust the air bag strength, 1-5 gears.
- Heating part: Press the icon or name to turn on the heating function, and the corresponding heating icon on the back of the human body will light up. Click the cursor again to turn off the heating function and the icon will turn off.
- Foot roller: The function is the same as the foot roller in automatic mode.



Turn off/on
Pause/Resume

/ Instructions for use

6) Manual

Press the "Menu Bar" and select "Manual" to automatically enter the manual interface. The manual interface displays the movement position and time of the movement. Operate some massage techniques, width adjustment, massage interval adjustment, massage intensity, and airbag intensity.

The lower column of the interface is for heating parts, foot rollers, shutdown, and pause.

● **Massage techniques:** Switch between 6 massage techniques, including kneading, beating, tapping, acupressure, kneading and massage.

● **Width adjustment:** 3 position options, wide, medium and narrow, only suitable for beating, tapping and acupressure techniques.

● **Massage interval adjustment:** 3 interval options, full, partial, and fixed-point massage.

● **Massage intensity:** 1-6 levels of massage intensity adjustment, acupressure massage is not effective.

● **Air bag strength:** 1-5 levels of air bag strength adjustment.

● **Movement position adjustment:** In local and fixed-point conditions, adjust to the best massage position by moving up and down.


● **Heating part:** Click the icon or name to turn on the heating function, and the corresponding heating icon on the back of the human body will light up. Click the cursor again to turn off the heating function, and the icon will turn off.

● **Foot roller:** The function is the same as the foot roller in automatic mode.




Turn off/on
Pause/Resume

/ Part name



/ Introduction to control panel functions




Shortcut key
operation panel

Touch operation panel

/ Instructions for use

一、 Turn on the power of the whole machine

- ① Turn on the power plug. ② Overall machine connection and power switch diagram



Turn the power switch on the lower back of the machine to the "I" (on) position

二、 Massage function operation control

1. Standby

In standby mode, press the "Standby" key on the upper left corner of the operation panel to turn on the device.

It can also be used through voice control commands and shortcut hand control.

In standby mode, press the backrest up or down button on the shortcut hand control to directly adjust the chair back up/down.

2. Start using

In standby mode, press the "Standby" button to start massage, and lie down on the backrest and legs to the set angle.

After the angle is in place, the massage chair will automatically detect the shoulder height position of the body shape.



/ Instructions for use

5) Automatic interface

Press "Menu Bar" to select "Auto" to automatically enter the automatic interface. The automatic interface mainly displays massage time, bluetooth, air bag strength, current mode name, massage amplitude, air bag position, machine The specific location of the core row. The lower column of the interface is for heating parts, foot rollers, shutdown, and pause.

● Heating part: Click the icon or name to turn on the heating function, and the corresponding heating icon on the back of the human body will light up. Click the cursor again to turn off the heating function, and the icon will turn off.

● Foot sole icon: In automatic mode, it will automatically activate the wheel function with the leg airbag. if click on the icon or name to first turn off the automatic mode wheel and airbag function, and then switch to manually turning on the wheel function. Click the icon or name again to turn on the scroll wheel function. The icon will light up and the intensity can be adjusted in 3 levels. After turning it on, click the icon or name again to turn off the scroll wheel function and the icon will turn off at the same time.

● In automatic mode, you can select the air bag mode in the "air bag interface" and adjust the air bag strength. Use the chair back and leg lift buttons in the "sitting interface" to adjust to the best angle for massage.



Turn off/ Pause/Resume

/ Instructions for use

4) Home-Settings

Setting interface: mainly composed of brightness, sound, massage time, screen off time, language, Bluetooth, voice, shutdown, pause and return functions.

- **Brightness:** You can adjust the screen display brightness higher or lower. Levels: 5 levels.
- **Sound:** The sound of touch operation can be raised or lowered, gear level: 5, Synchronized with the "+" "-" function in the upper left corner of the control panel.
- **Massage time:** Choose to set the massage time, 10-15-20-25-30 minutes.
- **Screen-off time:** Choose to set the screen-off time, 5-10-15-20-25 minutes. When the set time is up, the screen will automatically turn off, and you can wake it up by touching the panel directly.
- **Language:** 5 languages from different countries, Languages: Chinese, Russian, English, Korean, Vietnamese.
- **Bluetooth:** Turn the Bluetooth function on or off, and the corresponding icon lights up or goes out.
- **Voice:** After clicking, the entry voice interface will automatically pop up.



Return

Turn off/on
Pause/Resume

/ Instructions for use

1) Shoulder position compensation

After the detection is completed, enter the manual adjustment interface. You can use the up/down keys to compensate to the best position. If the shoulder position detection is already at the best position, you can press the "OK" key to directly enter "Automatic Interface", if there is no operation for 8 seconds, it will automatic transfer to the "Automatic Interface".

Button	Description
	Adjust the massage ball upward to the optimal shoulder position
	Adjust the massage ball downward to the best position on the shoulder



/ Instructions for use

2) Menu bar interface

Menu bar interface: The function menu bar consists of home page, automatic, manual, air bag, and sitting posture.

Home page interface: Easy massage, Queen slim, More Auto, Sleep mode, Fatigue recovery, and settings.



Turn off/on
Pause/Resume

3) Home page - more automatic interfaces

More automatic interface: 12 different automatic modes are set for users, so that users can choose different modes of massage.

12 modes:

Easy massage, Queen slim, Pain relief, Office mode, Sleep mode, Fatigue recovery, Shoulder focus, Waist relief, Lumbar Relaxation, Awaken vitality, Leisure mode, Exercise recovery



Turn off/on
Pause/Resume

/ Instructions for use



Turn off/on
Pause/Resume

Description of 12 automatic modes

Mode		Description	Strength
Group customization	Easy massage	The movement quickly kneads, taps, and relaxes the tense muscles throughout the body, promoting the recovery of blood circulation and unobstructed veins.	medium
	Queen slim	A gentle and comfortable deep massage that relieves body fatigue, relaxes the body, and provides the most comfortable massage experience.	low
	Leisure mode	Specially designed for the elderly, the movements and airbags on the soles of the feet use the lightest techniques to alleviate lower back pain and foot cramps.	low
Classic Places	Sleep mode	The massage techniques of kneading and finger pressure, combined with low-intensity air pressure massage, enable people to fall asleep more quickly, improve sleep quickly, and enhance sleep quality.	low
	Fatigue recovery	Simulate Thai stretching, use airbags to inflate and clamp the shoulders, arms, and legs, tap the movement, press down on the beautiful leg angle, stretch the muscles of the whole body, and turn off the machine flexibly	High
	Office mode	Full body press and push mode, with moderate technique and airbag force, neck and shoulder massage for a longer time, focusing on shoulder and neck press and push, to improve neck and shoulder soreness caused by long-term sitting for office workers.	medium
	Exercise recovery	Specially designed for exercise groups in fitness centers for athletes	low
	Pain relief	Through kneading, tapping, and finger pressure massage techniques, relieve shoulder muscle relaxation and relieve soreness.	medium
	Awaken vitality	By kneading and massaging the fingers and buttocks, the force is gentle and moderate, helping to restore physical fitness and relax muscles.	medium
Targeted massage	Shoulder focus	Key massage should be given to the shoulder and neck areas, with a high degree of thrust. The massage techniques mainly include kneading, tapping, and grasping to relax the muscles and relieve soreness.	High
	Waist relief	Focus on pushing the waist and back, with moderate thrust. Use kneading and tapping to relieve the tightness of the back and alleviate the soreness caused by prolonged sitting.	medium
	Lumbar Relaxation	Massage towards the buttocks with gentle force, increasing exercise and improving function through kneading and pounding.	low

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 0 centimeters from the device surface at all times, except for non-repetitive patterns with transient time intervals in the order of a second. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.