



Important Safety Precautions	Introduction	A Quick Look	Wired Charging	Solar Charging
<p>When using your Solar Wireless Speaker With Built-In Flashlight basic safety precautions should always be followed, including the following:</p> <ol style="list-style-type: none"> 1. READ ALL INSTRUCTIONS BEFORE USING YOUR SPEAKER. 2. Do not allow children or the infirm to play with your speaker without adult supervision. 3. Do not expose your speaker to excessive heat, flames or fire. 4. Do not expose your speaker to high humidity, moisture, or water. 5. Always press all buttons carefully. Do not manhandle your speaker. 6. Do not use in extremely dry environments, as this can lead to static discharge during usage. 7. Do not expose your speaker to extreme temperatures of hot or cold. 8. Do not attempt to repair this product yourself. Contact a qualified service center if your speaker is in need of service. 9. Do not drop, puncture, or expose your speaker to excessive trauma. 10. Your speaker is not intended for commercial use. 11. Do not place near objects that generate a strong magnetic field. 12. Use only the supplied charging cables. Unplug this device when not in use for long periods of time or during lightning storms. 13. Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information. <p>BATTERY WARNING: -This device is supplied with an integrated lithium battery. The battery cannot be replaced. Do not attempt to remove the battery from the device. -Do not dispose in fire or expose to excessive heat. -Do not crush, puncture, incinerate, or short circuit external contacts. -Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.</p> <p>CAUTION</p>	<p>Thank you for purchasing the Realtree Solar Wireless Speaker With Built-In Flashlight, item RLT6017. You can use your speaker with most Bluetooth devices to stream music. In order to get the best results when using this device, please read this manual closely before using.</p> <p>Features</p> <ul style="list-style-type: none"> -Playtime up to 4 hours -Strong Flashlight -Solar Panel Charging <p>Contents</p> <ul style="list-style-type: none"> -Solar Wireless Speaker -USB Charging Cable -User's Manual With Warranty Information 	<p>Overview</p> <p>Buttons</p> <p>1. Play/Pause Button 2. Volume Down Button 3. Volume Up Button 4. Mode Button 5. Power Switch 6. MicroSD Card Slot 7. Aux In Port 8. Charging Port 9. USB Port 10. Light Switch</p>	<p>To power your speaker, you must first charge the battery. You can charge the battery using the included USB charging cable or the attached solar panel. To charge using the included charging cable, follow the steps below.</p> <p>STEP 1. Insert one end of the included charging cable into the charging port on your speaker.</p> <p>STEP 2. Insert the other end into a suitable USB charging adapter.</p>	<p>Your speaker can also charge using the attached solar panel.</p> <p>Place the solar panel in direct sunlight. The solar panel charges the battery very slowly and is thus not intended to fully charge the speaker. It is designed to give you a little bit of extra charge capacity so that you can go for a longer period without needing a full charge.</p> <p>Do not charge the speaker in extremely hot areas, such as a car. While charging, it is recommended that you turn the speaker off.</p> <p>Solar Panel</p>

Bluetooth Pairing	Using Your Speaker	Maintenance and Care	FCC Statement	One Year Warranty	REALTREE
<p>Move the power switch to the ON position to power ON the speaker.</p> <p>Press the mode button to cycle through the speaker's different modes and set the speaker to Bluetooth mode.</p> <p>Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "RLT6017".</p> <p>To disconnect from Bluetooth, press the mode button to change modes or move the power switch to the OFF position to power OFF the speaker.</p>	<p>Mode Button Press to cycle through the speaker's modes, such as USB, MicroSD, Bluetooth, and Radio.</p> <p>Volume Up Button Press to play the next track. Press and hold to increase volume.</p> <p>Volume Down Button Press to play the previous track. Press and hold to decrease the volume.</p> <p>Play/Pause Button In radio mode, press for automatic channel search. In other modes, such as USB, MicroSD, and Bluetooth, press to play/pause. Press and hold to enable or disable True Wireless Stereo Pairing.</p> <p>Light Switch Set the light switch forward or back to turn on the LED lights or flashlight. Position the light switch in the middle to turn off the light and flashlight.</p> <p>Power Switch Move the power switch to the ON position to power ON the speaker. Move the power switch to the OFF position to power OFF the speaker.</p> <p>MicroSD Card Slot Slide a MicroSD memory card into the MicroSD Card Slot on your speaker. When in MicroSD mode, your speaker can play .MP3 music files from your card.</p> <p>USB Port Insert a USB thumb drive into the USB port on your speaker. In USB mode, your speaker will play .MP3 music files stored on the drive.</p> <p>Aux In Port Connect one end of an Aux cable to the Aux In port. Connect the other end to a compatible audio device's headphone jack to listen to music using a wired connection.</p>	<p>-Use a soft cloth or paper towel to clean your speaker. Never use any harsh chemicals or detergents for cleaning. Make sure your speaker is dry before charging.</p> <p>-When your speaker is not in use, it should be stored in a cool, dry place.</p> <p>-Never tug or yank on a cable while it is connected to your speaker. Connect and disconnect cables as carefully as possible.</p> <p>-Never expose your speaker to high temperatures or extreme cold.</p> <p>-Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information.</p>	<p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>FCC warning: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	<p>This warranty covers the original consumer purchaser only and is not transferable.</p> <p>This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.</p> <p>What Is Not Covered by Warranty Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.</p> <p>To Obtain Warranty Service and Troubleshooting Information: Call 1-800-592-9541 for 24/7 support.</p> <p>To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepair.</p>	
<p>TWS Pairing</p> <p>TWS Pairing enables the speaker to pair with another RLT6017 Solar Wireless Speaker to play music in sync.</p> <p>Power ON both speakers. Press and hold the play/pause button to turn ON/OFF True Wireless Stereo. Enable TWS for both speakers.</p> <p>When both Solar Wireless Speakers are ON and have TWS enabled, they will automatically pair together. When paired, go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "RLT6017".</p>	<p>Specifications</p> <p>ITEM NUMBER: RLT6017 SPEAKER PLAY TIME: UP TO 4 HOURS*</p> <p>*Applicable at 50% of maximum volume. Results will be lower when volume is higher.</p>	<p>2025 CSI Edison, NJ 08817 Tech Support 800.592.9541</p> <p>* All brand, product names and logos are trademarks or registered trademarks of their respective companies. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.</p>			