




<p><b>ERAZER</b> Invested By Lenovo</p>  <p><b>ERAZER Wireless Earbud XF39 Product Manual</b></p>	<p><b>Specification of Product</b></p> <p>Model of Product: ERAZER XF39 Version: V6.0 Effective Distance: Approx. 10m Speaker Diameter: φ12mm Impedance: 16Ω Frequency Response: 20Hz-20KHz Microphone Sensitivity: -42dB±3dB Earphone Input: 5V±50mA Charging Case Input: 5V±300mA Charging Case Output: 5V±100mA Earphone Battery Capacity: 50mAh Charging Case Battery Capacity: 300mAh Duration: Approx. 6 H (Earphone) Earphone Charging Time: Approx. 2 H Charging Time of the Charging Case: Approx. 2 H</p> <p><b>Item list</b></p> 	<p><b>Welcome to ERAZER Wireless Earbud</b></p>  <p><b>Take out and pair it</b> When using for the first time, take out the left and right earphones at the same time. When the red light and blue light of the earphones flash alternately, the earphones will enter the automatic pairing mode.</p>	<p><b>How to wear headphones correctly</b></p> 		<p><b>Product Description</b></p> <p>Multi-function key touch position Bluetooth LED indicator light Charging Contacts Type-c Interface Charging Indicator</p>	<p><b>Touch Operation</b></p> <p><b>Connect with Bluetooth device</b></p> 	<p><b>Indicator Light Description</b></p> <ul style="list-style-type: none"> <li>When the headset is turned on: the red light and the blue light flash alternately.</li> <li>When the headset is turned off: the red light flashes three times and then goes off.</li> <li>Successful pairing of left and right ears: the red and blue lights on the main ear flash alternately, while the light on the secondary ear goes off.</li> <li>Bluetooth device successfully connected: no light.</li> <li>Headphone charging: The red light on the headphones remains on. After being fully charged, the red light on the earphones turns to blue and goes off.</li> <li>Charging of the Charging case: The white indicator light of the charging case flashes in a stepped manner: When the first white light on the left is constantly on, the battery level of the charging case is about 20%-30%; When the second white light on the left is constantly on, the battery level of the charging case is about 45%-55%; When the third white light on the left is constantly on, the battery level of the charging case is about 70%-80%; When the fourth white light on the left is constantly on, it indicates that the charging case is approaching saturation. After the charging case is fully charged, the charging case indicator light goes off.</li> </ul>
--	---	---	--	---	--	---	---

 <p><b>Power On</b> Auto power on: The Earphone are taken out of the charging case, the Earphone will be powered on, with the prompt sound of "Du". Manual power-on: Long press for 3 seconds, the Earphone will be powered on, with the prompt sound of "Du". <b>Power Off</b> Auto power off: Put the Earphone in the charging case, the Earphone will be powered off, with the prompt sound of "Du". Manual power off: Long press for 5 seconds, the Earphone will be powered off, with the prompt sound of "Du".  Note: After powering on, if it is not paired with a Bluetooth device for 3 minutes, it will automatically shut down; Exceeded the effective connection distance and did not connect to the Bluetooth device, it will automatically power off after 3 minutes, with the prompt sound of "Du".</p>	<p><b>Once Press</b></p>  <p>Music mode Play/Pause Phone mode Call Answer/End</p> <p><b>Double Press</b></p>  <p>Music mode Volume up Double press the right ear: Double press the left ear: Volume decreases</p>	<p><b>Triple Press</b></p>  <p>Music mode Triple press on the left ear: Triple press on the right ear: Previous song next song</p> <p><b>Switch between game mode and music mode</b></p>  <p>Game mode Press and hold the multi-function button on the right ear for 2 seconds Music mode Press and hold again for 2 seconds</p> <p>Note 1: When using one earphone, you cannot switch between game mode and music mode. Note 2: The factory setting defaults to music mode</p>	<p><b>Wake up voice assistant</b></p>  <p>When using both ears, press and hold the left ear multi-function button for 2 seconds to activate the voice assistant. When using one earphone, press and hold the left (or right) earphone for 2 seconds to activate the voice assistant</p> <p><b>Wireless pairing mode</b></p> <p>1. When there is no pairing record for the left and right earphones, the left and right earphones will automatically pair after they are turned on. After successful pairing, there will be two beeps. 2. When the left and right earphones have pairing records, they will automatically connect back when they are turned on, and the prompt will sound "beep".</p>	<p><b>FCC ID: 2BHJR-XF39</b></p> <p><b>FCC Warning:</b> Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation. <b>Note:</b> This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p>	<p><b>RF warning for Portable device:</b> The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <table border="1" data-bbox="2403 842 2725 953"> <tr> <td><b>US REP</b></td> <td>Company Name: MIRAMONT SOLUTIONS LLC Address: 19 GEORGETOWN, IRVINE, CA 92612 United States Contact Name: Wenli Wang Telephone No: (951) 401-3633 Email: wenliwang@miramontsolutions.com</td> </tr> </table>	<b>US REP</b>	Company Name: MIRAMONT SOLUTIONS LLC Address: 19 GEORGETOWN, IRVINE, CA 92612 United States Contact Name: Wenli Wang Telephone No: (951) 401-3633 Email: wenliwang@miramontsolutions.com	<p><b>ERAZER</b></p> <p><b>Customer Service Email:</b> contact@yhemi.net</p>
<b>US REP</b>	Company Name: MIRAMONT SOLUTIONS LLC Address: 19 GEORGETOWN, IRVINE, CA 92612 United States Contact Name: Wenli Wang Telephone No: (951) 401-3633 Email: wenliwang@miramontsolutions.com							