


























<div>ERAZER Invested By Lenovo</div> <div></div> <div>ERAZER Wireless Earbud XF56 Product Manual</div>	<div>Specification of Product</div> <div>Model of Product: ERAZER XF56 Version: V6.0 Effective Distance: Approx. 10m Speaker Diameter: φ13mm Impedance: 29Ω Frequency Respinse: 20Hz-20KHz Microphone Sensitivity:-42dB±1dB Earphone Input: 5V≈30mA Charging Case Input: 5V≈300mA Charging Case Output: 5V≈60mA Earphone Battery Capacity: 30mAh Charging Case Battery Capacity: 300mAh Duration: Approx. 4 H (Earphone) Earphone Charging Time: Approx. 1 H Charging Time of the Charging Case: Approx. 2 H</div> <div>Item list</div> <div><div>Charging case *1</div><div>Headphones *1</div><div>Instruction *1</div><div>Lanyard *1</div><div>Charging cable *1</div></div>	<div>Welcome to ERAZER Wireless Earbud</div> <div></div> <div>Take out and pair it</div> <div>When using for the first time, take out the left and right earphones at the same time. When the white light and ice blue light of the earphones flash alternately, the earphones will enter the automatic pairing mode.</div>	<div>How to wear headphones correctly</div> <div>1</div> <div>2</div> <div>3</div> <div>4</div>	<div>Product Description</div> <div><div>Multi function key touch position</div><div>Bluetooth LED indicator light</div><div>Charging Contacts</div><div>Charging case digital display screen</div><div>Charging Indicator</div></div> <div></div>	<div>Touch Operation</div> <div>Connect with Bluetooth device</div> <div><p>Open the Bluetooth settings option of the Bluetooth device to be paired, enter the options and find the Bluetooth pairing name of the headset "ERAZER XF56". Click the pairing name to pair.</p></div> <div></div>	<div>Indicator Light Description</div> <div><ul style="list-style-type: none">When the headset is turned on:the white light and the ice blue light flash alternately.When the headset is turned off: the white light flashes three times and then goes off.Successful pairing of left and right ears: the white and ice blue lights on the main ear flash alternately, while the light on the secondary earphone goes off.Bluetooth device successfully connected: no light.</div> <div><ul style="list-style-type: none">Earphone charging: The digital display screen of the charging case remains open, and the white light on the headphones is still on. After being fully charged, the white light of the earphones will turn off, and the digital display screen of the charging case will also turn off.Charging of the Charging case: The digital display screen of the charging case flashes, and after being fully charged, the digital display screen of the charging case always shows 100.</div>	
<div></div> <div>Power On Automatic power on: Remove the earphones from the charging case, The earphones will be powered on and emit a beep sound. Manual power on: Press and hold for 3 seconds, the headphones will open the connection Accompanied by the beeping sound of "Du". Power Off Auto power off: Put the Earphone in the charging case, the Earphone will be powered off, with the prompt sound of "Du". Manual power off: Long press for 5 seconds, the Earphone will be powered off, with the prompt sound of "Du".</div> <div>Note: After turning on the device, if it is not paired and connected to the Bluetooth device for 3 minutes, it will automatically shut down; Exceeded the effective connection distance and did not connect to the Bluetooth device. After 3 minutes, it will automatically shut down with a beep sound.</div>	<div>Once Press</div> <div><div>Music mode</div><div>Phone mode</div><div>Play/Pause</div><div>Call Answer/End</div></div> <div>Double Press</div> <div><div>Music mode</div><div>Double press the right ear: Volume up</div><div>Double press the left ear: Volume decreases</div></div>	<div>Triple Press</div> <div><div>Music mode</div><div>Triple press on the left ear: Previous song</div><div>Triple press on the right ear: next song</div></div> <div>Switch between game mode and music mode</div> <div><div>Game mode</div><div>Music mode</div><div>Press and hold the multi-function button on the right ear for 2 seconds</div><div>Press and hold again for 2 seconds</div></div> <div>Note 1: When using one earphone, you cannot switch between game mode and music mode.</div> <div>Note 2: The factory setting defaults to music mode</div>	<div>Wake up voice assistant</div> <div></div> <div>Wake up voice assistant</div> <div>When using both ears, press and hold the left ear multi-function button for 2 seconds to activate the voice assistant.</div> <div>When using one earphone, press and hold the left (or right) earphone for 2 seconds to activate the voice assistant</div> <div>Phone mode</div> <div>Press and hold the left (or right) ear multi-function button for two seconds: call rejection</div>	<div>Clear Bluetooth pairing history</div> <div>When two ears cannot be paired, it is necessary to clear all connected devices and click on the left and right earphones 5 times respectively.</div> <div></div> <div>Wireless pairing mode</div> <div>1. When there is no pairing record for the left and right earphones, the left and right earphones will automatically pair after they are turned on. After successful pairing, there will be two beeps.</div> <div>2. When the left and right earphones have pairing records, they will automatically connect back when they are turned on, and the prompt will sound "beep"</div>	<div>FCC ID: 2BHJR-XF56</div> <div>FCC Warning: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</div>	<div>*RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</div> <div>US REP</div> <div>Company Name: MIRAMONT SOLUTIONS LLC Address: 19 GEORGETOWN, IRVINE, CA 92612 United States Contact Name: Wenyi Wang Telephone No: (951) 401-3633 Email: wenyiwang@miramontsolutions.com</div>	<div>ERAZER</div> <div>Customer Service Email: contact@yhemi.net</div>