


# T33A 说明书-20250305

**Casely**



**Power Pod 2 User Manual**


**Package Details**

- 1x Power Pod 2
- 1x Type C USB to Type C USB charging cable

**Features**

- Magnetic Wireless Charging
- MagSafe® Compatible Technology
- Portable Wireless Charging
- Accurate LED Power Indicators
- High Quality, Safe Polymer Battery

**Product Diagram**



**Step 1: Indicator lights**

Click the power button once to check if your Power Pod is charged.

If the indicators light up, continue to step 3.

If the last light begins flashing, continue to step 2.

**About Power Indicator Lights**

Check power indicator lights to monitor power status

Checking remaining power:

Click the button. If one light is on, it means the PowerPod has less than 25% power remaining. Two lights is 50%, three lights is 75%, and four lights is 100%. When the last light begins flashing, the battery level is less than 5% and will need to be recharged.

**Step 2: Charge your Power Pod**

Charge the Power Pod using the included Type C USB to Type C USB charging cord

The indicator lights will flash in a row when the Power Pod is successfully charging

Once it is fully charged, all 4 lights will light up.

**Step 3: Place your Power Pod on the back of your device**

If using a built-in MagSafe® magnet, align Power Pod to the center of device.

The Power Pod should snap into place when the magnets align.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

**Step 4: Power on & begin charging**

**How to use your PowerPod:**

Click the power button once to power on  
Click the power button twice to power off



Click the power button once to turn the Power Pod on.

When the Power Pod detects an external device, the red light will change to green and begin charging.

If the light is red, the Power Pod is not charging an external device, but it is powered on and ready to charge an external device.

**Step 5: Stop charging & power off**

Click power button **twice** to power off the Power Pod

When Power pod is powered off, it will not charge even when a device is still connected to your Power Pod (wired or wirelessly).

**Step 6: Recharge your Power Pod**

Your Power Pod indicator lights will begin flashing when less than 5% of battery is remaining.

**Refer to step 2 to recharge your Power Pod.**

**Step 4 (continued): Power on & begin charging**

**Wireless Charging:** Charge your phone wirelessly



**Step 5 & 6: Stop charging, power off & recharge**

**Troubleshooting**

**If the PowerPod will not charge:**

- Check that charging cable is working & plugged into a wall power adapter.

**If the Power Pod is not charging your device:**

- Confirm that your Power Pod is charged & powered on. Refer to Step 1 & 4.

**If your MagSafe® compatible device is not magnetically snapping to Power Pod:**

- Confirm that your phone case is also MagSafe® compatible. If your case is not MagSafe® compatible, you will have to remove your case, or attach an adhesive magnetic ring to the back of your case (refer to step 3).
- If you need a MagSafe® compatible case with a built-in magnet, you can shop our collection of cases here: [getcasely.com/MagSafe-cases](http://getcasely.com/MagSafe-cases)

**Specifications**

Model	T33A
Name	Power Pod 2 - Magnetic Wireless Charging Bank
Battery	7.74V, 19.35Wh (2500mAh*2PCS)
Type-C1 Input/Output	5V-3A/9V-2.22A/12V-1.67A
Type-C2 Input/Output	5V-3A/9V-2.22A/12V-1.67A
Wireless Output	15W (Max)
Rated Capacity	3300mAh(5V/3A), 1900mAh (9V/2.22A), 1400mAh(12V/1.67A), 1200mAh(Wireless 15W)

**Power Pod Compatibility**

**Built-in Magne**

Compatible with iPhone 12 & later (with MagSafe® compatible case). Power Pod can be magnetically secured to Non-MagSafe devices & cases using the Adhesive Magnetic Ring (refer to Step 3)

**Wireless Charging**

Compatible with Qi Wireless Charging Phones, such as iPhone 8 & later, Samsung, Google, AirPods 2, AirPods Pro, AirPods 3

**Wired Charging**

Compatible with all devices. Requires Type C USB-C charging cable (not included).

**Notes & Warnings**

PowerPod can lose their battery function if they are not used for a long time. Charge the device at least every 3 months to maintain its functionality.

This device may heat up during charging, which is normal as long as it is below 55°C

Always keep this device dry and do not clean with chemical agents

Go green and recycle this device at designated electronic recycling drop-off centers

Do not use it to charge devices with incompatible current and voltage, which could result in fire

Do not crush, disassemble, impale or put this device in humid conditions

Children must use it under the guidance of adults

**WARNING:**

Risk of Fire and Burns. Do Not Open, Crush, Heat Above 45°C or Incinerate. Follow Manufacturer's Instructions.

**GETCASELY.COM**

Made in China

**IMPORTANT SAFETY INSTRUCTIONS**



